

Manual

ProtoMat S100

English, version 2.0

LPKF Laser & Electronics AG

Osteriede 7
D-30827 Garbsen

Telephone : ++ 49 - 51 31 - 70 95 - 0
Telefax : ++ 49 - 51 31 - 70 95 - 90
eMail : lpkf@lpkf.de
Homepage : <http://www.lpkf.de>

Copyright (C) 2006 LPKF AG

No part of this document may be reproduced or transmitted or used for any purpose without the express written permission of LPKF. The information contained in this document is subject to change without prior notification. LPKF assumes no liability for the use of this document. In particular for damage resulting from information, which is present, not present or erroneous.

Trademarks: HP-GL is a trademark of the Hewlett-Packard Corp. All other trademarks are the property of the specific proprietor.

Item number: 117269

Notes on this Manual

The information contained in this document is subject to change without previous notice. No part of this document may be reproduced or transmitted for any purposes in any form without express written permission of LPKF AG. All efforts were made to ensure that this document is as accurate as possible and that the information contained therein is complete. Nevertheless, LPKF AG cannot assume any liability for its use or for any violations of patent or other rights held by third parties resulting there from.

The operator of the machine is responsible for ensuring that the following points are observed. Ensure that

- the machine is used only for its intended purpose.
- the machine is operated only in a perfect functional condition and particularly that the safety equipment is checked regularly for proper function.
- required personal protective equipment for the operating, maintenance and repair personnel is available and used.
- the operating instructions are always kept at the location where the machine is operated and are in a legible and complete condition.
- only sufficiently qualified and authorized personnel operate, service and repair the machine.
- this personnel is trained regularly on all questions regarding labor safety and environmental protection as well as is familiar with the operating instructions and particularly the safety precautions contained therein.
- all safety and warning information attached to the machine is not removed and remains legible.

I. Outline

This Manual is subdivided into the following chapters:

1. Introduction
2. Intended use
3. Safety notes
4. Scope of delivery
5. Layout of machine
6. Bringing into service
7. *BoardMaster* User Surface
8. Introduction to the Basic Functions
9. *BoardMaster* Functions
10. Menu Bar
11. Operating procedures
12. Practical tips
13. Other *BoardMaster* Functions
14. Special Applications
15. Appendix
16. Options
17. Technical Data
18. Declaration of conformity (German)
19. Declaration of conformity
20. Index

II. Conventions used in this manual

Bold text is used to emphasize important information.

Illustrations are numbered. Example: Fig. 5

- › Prompts for actions are identified with an arrow.

Italic sections are used to indicate the reactions consequent on an action.

Word printed in *italics* mark proper names.

Key inscriptions and menu terms are printed in **BOLD CAPITALS**.

III. Notes on the symbols used



Danger! This symbol is used to highlight danger to life or health.



Caution! This symbol is used to identify hazards which may cause damage.



Note! This symbol is used for notes intended to help you avoid faults in operation or to help you improve your procedures.



Machine greenhorn:

This symbol indicates important tips and information for those not already familiar with LPKF milling technology.

IV. Terminology

Copper laminate : Special extremely thin base material used for pressing multilayers.

Base material : Circuit board material coated with copper foil

Solder resist foil : Special foil with cutouts for solder connections on a circuit board.

BoardMaster : Machine control software.

CircuitCAM : Software for data processing

V. Target Group

This manual is intended for personnel who already possess basic knowledge of production of circuit boards for the electronic sector.

VI. Intended Use

The machine described in this manual is intended exclusively for milling and drilling standard commercial circuit board materials in the electronic industry. Any other type of use of the machine is expressly prohibited.

Contents

1.0 Introduction	11
2.0 Intended Use	13
3.0 Safety Notes	14
4.0 Scope of Delivery	16
4.1 Accessories (available as option)	16
5.0 Layout of Machine	17
5.1 Initial Setup	17
5.2 Orientation Axis / Positions	20
5.3 Machine Components and Connections	21
5.4 Serial Interface(s) / USB Connection	22
5.5 Functional Units	24
5.5.1 The Machining Head	24
5.5.1.1 Machining Spindle with Collet	25
5.5.2 Working Depth Limiter	25
6.0 Bringing into Service	26
6.1 Installation	26
6.1.1 System Prerequisites	26
6.1.2 Installation	26
6.1.3 Directories Generated During Installation	28
6.2 Installation of the USB driver	28
6.3 Introduction	29
6.3.1 HOME Position and Reference Hole System	29

6.4	Switching On the Circuit Board Plotter	30
6.4.1	Starting BoardMaster	31
6.4.2	Wait Message	33
6.5	Switching Off the Circuit Board Plotter	34
7.0	BoardMaster User Surface	35
7.1	Function Bar	36
7.2	Brief Summary of Function Bar	37
7.2.1	Status information	38
8.0	Introduction to the Basic Functions	39
8.1	Creating a New Reference Hole System	40
8.2	Preparing and putting on base material	42
8.3	Working with Production Data and Phases	43
9.0	BoardMaster Functions.	50
9.1	Changeable Settings	50
9.2	Positioning Functions	50
9.3	Control Functions for Manual Control.	51
9.4	Selection functions	52
9.5	Control Functions for Production Phase.	53
9.6	Camera Functions (only for S100 with camera option) 54	
9.7	Tool Holder	55
10.0	Menu Bar	56

10.1	Go To Menu	56
10.2	CONFIGURATION Menu	57
10.2.1	Serial Interface	57
10.2.2	Machine Settings	59
10.2.3	Tool Parameter	61
10.2.4	Heads Dialog Box	63
10.2.5	Adjust Camera Offset	64
10.2.6	Phase... - Production Phases	66
10.2.7	Defining the Base Material Size	67
10.3	File Menu	69
10.4	Edit Menu	70
10.4.1	Assigning Tools	71
10.4.2	Placing Projects	73
10.4.3	Select Tools	75
10.5	Reload Dialog Box	75
10.6	View Menu	77
10.7	Selecting Production Phase	78
10.8	Automatic Tool Change	79
11.0	Operating Procedures	81
11.1	Fastening the Base Material	81
11.2	The tools	82
11.3	Drilling	83
11.4	Insulation Milling	83
11.5	Contour Milling in Circuit Board Material	84
11.6	Milling Wide Insulation Channels	85
11.7	Cleaning Circuit Boards	86

12.0 Practical Tips	87
13.0 Other BoardMaster Functions	89
13.1 Learning Fiducial (Option)	89
13.2 Setting fiducials	93
13.3 Adjusting Milling Depth.....	96
13.4 Drilling Reference Holes in Base Material	97
13.5 Special Features.....	99
13.5.1 Tool box dialog box	99
13.5.2 Service password dialog box.....	101
14.0 Special Applications	102
14.1 Front Panel Engraving	102
14.2 Milling Solder Resist Foils	102
15.0 Appendix	104
15.1 Switching over the device voltage	104
15.2 Maintenance.....	107
15.2.1 X Axis, Y-Axis and Z Axis	107
15.2.2 Maintenance on Working Depth Limiter	108
15.2.3 Maintenance instruction for Machining Head .	112
15.2.3.1 Cleaning the collet	112
15.3 Checking and adjusting the tool positions by means of the camera	113
15.4 Checking and adjusting tool positions without camera 114	
15.5 The Teach-In Dialog Box	115

16.0 Options	118
16.1 Installing the camera	118
16.2 Mounting the Vacuum Table	120
16.3 Spring setting at the machining head	123
17.0 Technical Data	124
18.0 Declaration of Conformity (German) . . .	125
19.0 Declaration of Conformity	127
20.0 Index	129

1.0 Introduction

The machine described in this manual is a circuit board plotter suitable for producing circuit board prototypes and engraved films. It consists basically of a base plate, an X/Y motion system and a machining head. This machining head can be moved along both axes with the aid of the X/Y motion system. The machining head can also be lowered. This results in two basic processing possibilities. First, a channel can be milled with a milling cutter in a piece of base material fastened to the base plate by moving the lower machining head. Second, a hole can be drilled in the base material by lowering the machining head when it is standing still and a drill installed.

This circuit board plotter offers very high precision in machining and high machining speed. Almost completely automatic processing is possible due to other special functions like fully automatic tool change and the adjustable depth with which the tool penetrates the base material during drilling, which can be set via the software. All this helps to minimize the effort required for operation in small series production. Another special feature is the integrated vacuum table which enables the processing of soft and flexible substrates (special PCB materials).



The machine is controlled and operated almost completely by the *BoardMaster* software. Always read this manual carefully before starting work with the machine. After unpacking, set up your circuit board plotter on a suitable table (see chapter „Initial Setup“ on page 17 for a description) and inspect all of the components described in the following chapters precisely, i.e. familiarize yourself with the mechanical control possibilities. This will make it easier when you then start up the machine in combination with the software with the aid of the quick start instructions or the *BoardMaster* chapters.

LPKF *BoardMaster 5.0 for Windows™* is a program for automatic control of HP-GL-compatible LPKF circuit board plotters.

LPKF *BoardMaster* is capable of reading in, displaying and processing production data in LMD format (generated in LPKF CircuitCAM) as well as production data generated in HP-GL format

BoardMaster takes over complete control of the circuit board plotter. The WYSIWYG (What You See Is What You Get) display for the data to be processed, manual control of the circuit board plotter on the *Windows* surface as well as the present tool library with all required information ensures virtually complete automation of circuit board prototype production.

This Manual shows you the path from LMD/HP-GL circuit board data generated by *CircuitCAM* or other programs, over job preparation right up to completion of the circuit board prototypes with the circuit board plotter.

The Manual introduces the basic control possibilities of *BoardMaster* step by step, allowing you to quickly complete your first circuit board in a simple manner.

Basic use of the *Windows* surface is not covered in this manual. If you are not familiar with the use of the various *Windows* objects, please first refer to your *Windows* documentation.

In order to ensure that any possible guarantee claims are honored, always follow the instructions in this manual before starting up the machine. Machines exported to other EU countries are subject to the guarantee terms in that country.

Now we hope you enjoy familiarizing yourself with your circuit board plotter.

2.0 Intended Use

The machine described in this manual is exclusively designed and constructed for the machining of commercially approved materials for the production of printed circuit boards or front plates. This comprises especially the following working steps:

Machining of all one-sided and double-sided board types in the usual packing density (FR3, FR4, FR5, G10), flexible substrates, RF substrates, drilling test adapters, structuring film patterns, producing solder frames for PCB assembly, SMD fine line technology, contour-milling, engraving of front panels or labels, depth milling of rigid or flexible boards, depaneling and reworking of populated and unpopulated boards, machining of housings and multilayers up to 8 layers in combination with MiniContac III and MultiPress-II.

Any other use is explicitly forbidden! Danger of damage to material or personal injury, and any guarantee claims are excluded!

3.0 Safety Notes



Danger: To ensure safe work with the circuit board plotter, the user should read this manual as well as the enclosed documentation and particularly the safety precautions in bold face print!



- **Keep your workplace orderly. Disorder at the workplace increases the danger of an accident!**
- **Take surrounding influences into consideration: Do not subject the electric machine to water or water spray. Do not use the circuit board plotter in moist or wet surroundings. Provide for good illumination. Never use the machine in areas endangered by fire or explosion.**



- **Keep children away from the working area! Ensure that children cannot touch the machine or connection line!**



- **Wear suitable work clothing! Do not wear wide clothing or jewelry. This can be caught by moving parts!**
- **Wear a hair net if you have long hair! Otherwise, your hair can get caught in a rotating tool!**



- **Care for your machine and the accessories properly and observe the maintenance instructions! Check the plug and cable regularly and if damaged have replaced by an authorized electrician!**



- **Before any type of maintenance or cleaning work on the machine, disconnect the power plug!**
- **Always be attentive! Observe your work and proceed rationally. Do not use the machine if you are unconcentrated!**



- **Always work with the vacuum on! Dusts resulting during operation of the machine may pose a health hazard and must therefore be evacuated!**



- **Check the machine regularly for damage! Ensure that all parts are installed correctly and that all conditions are fulfilled for proper operation as intended.**



- **Use only accessories and add-on equipment specified in the operating instructions or recommended or prescribed by the manufacturer! Use of other tools or accessories can cause damage to the machine or pose an injury hazard for the user!**

- **Have the machine repaired by authorized personnel! The circuit board plotter fulfills all applicable safety regulations. Repair should be performed only by qualified personnel using genuine parts, because improper repairs can pose an injury hazard for the user**

- **Caution when closing the machine hood! Danger of injury to hands!**

- **Never reach into the machine while it is running!**

- **When using a machine with housing: do not open housing while machine is in operation, danger of injury!**



- **Caution! Machine changes motion speed automatically during operation!**



- **Change tools only with the machining head spindle stopped! Injury hazard!**



- **When changing tools manually, always insert tool into chuck against stop!**

- **When performing manipulations on the machine, never operate the controlling PC simultaneously.**

- **Never reach into the traversing range of the running machine! The XY positioning system may move very fast. For this reason the handling also of auxiliary tools in the area of the base plate is strictly prohibited. Shear force may e.g. cut of fingers**

- **The safety of the machine can no longer be guaranteed if modifications are made to the machine by the user and the guarantee is invalidated!**



- **Observe that some materials can produce carcinogenic dust or dangerous gases during processing. Obtain information from material suppliers.**



- **Eating, drinking or smoking while working with the circuit board plotter is prohibited! The danger exists of ingesting toxic substances through the mouth! Never leave food or beverages open in the workroom (dust deposit!).**

- **When using chemicals, please observe the instructions on the containers or any separate safety data sheets!**



- **Wear suitable protection gloves during the exchange of material of the machine base plate. Danger of cutting due to sharp edges of the metall supports!**

- **When the cover is opened the present command is executed and then the machine will stop and no more commands can be given!**



- **Ensure that your computer is properly connected to the line power and to the circuit board plotter!**



- **Ensure that no one is present in the hazard area of the circuit board plotter during data transfer between *BoardMaster* and the circuit board plotter!**

- **Ensure that no one can enter the hazard area of the circuit board plotter and come into contact with the tools during operating phases controlled by *BoardMaster*!**



- **Ensure that it is not possible for unauthorized persons to operate *BoardMaster* when working with the circuit board plotter, for example during manual tool change or alignment of the base material!**

- **In the event of an emergency, shut off the circuit board plotter and PC connected to the circuit board plotter immediately!**

- **Also observe other safety precautions in this manual!**

4.0 Scope of Delivery

- 1 Machine unit LPKF *ProtoMat S100* with integrated electronic circuitry
- 1 Connection cable machine - PC (USB or serial)
- 1 Set accessories (foot of the working depth limiter, adhesive tape, various Torx tools, 5 reference hole pins, tweezers, brush, 2 red reference hole strips, 2 reference hole drills 2.95 mm, set of fuses)
- 1 Power cable
- 1 Piece base material (fixed on machine base plate)
- 1 Manual *ProtoMat S100* machine and software *BoardMaster*
- 1 CD ROM with software program *BoardMaster*
- 1 Manual software *CircuitCAM*
- 1 Pre-assembled hood
- 1 USB cable
- 1 USB repeater
- 1 pneumatic air supply unit (compl.)

4.1 Accessories (available as option)



- 1 Vacuum system with fine mesh filter and integrated automatic switch, adjustable exhaust power and automatic filter control. The vacuum system is switched on and off via the machining spindle.
- **Danger: The fine filter is required particularly for processing materials containing fiber glass such as FR4 base material! Otherwise, the hazard exists of carcinogenic dust particles escaping!!**
- Vision System
Camera-based positioning system for fiducial recognition
- LPKF *ProConduct*
System for through-plating with paste
- Vacuum table
System for fixing rigid or flexible materials free from distortion or warp

5.0 Layout of Machine

5.1 Initial Setup

- › Lift the cover of the cardboard box (1 in figure below) and remove the cardboard below
- › Remove the software package and the manuals.
- › Pull the styrofoam parts (3) at the side upward out of the box and lift the cardboard sidewalls (2) .
- › Remove the protective foil.
- › Put the circuit board plotter on a horizontal support capable of bearing the load.

Figure 1: Cardboard packing of the ProtoMat S100



- 1- Top cover of cardboard machine packing
- 2- Cardboard sidewalls (or frame)
- 3-Styrofoam protection at the sides
- 4- Place for manuals




Note: The machine should be positioned on a level and solid surface to prevent malfunctions and erroneous operation!

- › Remove securing devices (see 1, 2 and 3 in following figure) before switching on the plotter !!! Also remove any residual glue remaining on the board.



Caution! Should you switch on the plotter without having removed the transport securing devices first, we will not accept any guarantee claims for resulting damage!!!

Figure 2: Transport sealings



- › After the removal of all the transport sealings, the foot of the working depth limiter (4 in figure above, contained in the accessories set supplied with the delivery) has to be inserted in the working depth limiter underneath the mill/drill head! To do this, hold the machining head tight with your other hand!



Note: If the software *BoardMaster* should already have been started when the foot is being inserted and should the machining head not be held firmly, then an error message appears as the machining head is moving outside of the movement border.


- › Then connect the LPKF *ProtoMat* machine to the computer (COM 1, COM 2, or USB) with the Connection cable (Sub-D to RJ45 Connector).



Note: The machine can only be operated at COM1 to COM32. If a renumbering of the ports should be required, please read the Windows-Help file.

- › Remove the protection covers from the connectors and connect the RJ45 Connector with socket named “RS232/CAN” and the Sub-D Connector to COM1 or COM2 on the PC or the USB cable to the USB socket.
- › Connect the power cable on the LPKF *ProtoMat* machine to the line power. To do this, pull the power cable from the backside of the machine to the front until it reaches the main switch.


Figure 3: Mains connection, main switch, voltage switch-over



1- Mains connection, main switch and switching the voltage

- › Screw the vacuum hose in the connecting piece (counter-clockwise) and attach this to the adapter, see figure below.

Figure 4: Connection vacuum system



1 Exhaust adapter 3 Vacuum hose
2 Connecting piece

- › Attach the loose vacuum hose over the circuit board plotter to the appropriate connection on the machining head.
- › Connect the control cable for the exhaust system on the rear of the machine (see „Machine Components and Connections“ on page 21)




Note: Please save all transport retainers as well as the packaging for re-use if the machine is transported again.

5.2 Orientation Axis / Positions

The machining head can move along 3 axes. These axes are called the X, Y and Z axes. Definition of the axes is important for you during operation so that you always know where the table is moving. In the *BoardMaster* software, the motion paths are described exclusively according to these axis designations.

Figure 5: Orientation axes




Z-Axis: Lifting/lowering the machining head

- 1- Pause position:
The machine is moved to this point to install or turn the material to be processed
- 2- HOME position
- 3- Zero position:
The machine is moved to this point after switching on (machining head on the left, table to the front).

5.3 Machine Components and Connections

Description of the front view:


Figure 6: Front view
LPKF ProtoMatS100



- | | |
|-------------------|-------------------------------|
| 1- Hood | 4- Tool magazine |
| 2- Vacuum hose | 5- Displaceable machine table |
| 3- Machining head | |

Description of rear view:


Figure 7: Rear view, connections



- | | |
|--|---|
| 1- Mains cable | 5- Serial connection (RS232/CAN - connection socket) |
| 2- Connecting cable camera - PC (option) | 6- Connection hood |
| 3- Status display „Ready for operation“ | 7- Control cable für collet and pneumatic working depth limiter |
| 4- USB cable | 8- Control cable for vacuum system |

In the following figure you see how tools are placed in the tool magazine. For the order and the exact position of the tools please refer to the corresponding recommendation in the *BoardMaster chapter*.


Figure 8: Tools in tool magazine



5.4 Serial Interface(s) / USB Connection

The SERIAL1 is connected to a serial interface of the computer by means of the supplied null modem cable.

Wiring of the connecting cable is as follows:



The cable screening protection is connected only on the side of the PC (socket).

The following parameters must be observed:

Baud rate:	57600
Parity:	None
Data bit:	8
Stop bit:	1
Flow control (Windows XP):	Hardware
FIFO-buffer:	on (max. speed)




Note: the serial interface at the PC is configured under Windows in the system control.

Alternatively the connection can be done using the USB connection. Connect the USB cable with the USB sockets of the circuit board plotter and the PC. The optional camera can only be connected to a USB 2.0 port.



Note: USB can only be used via the LPKF USB repeater! For the installation of the USB driver see „Installation of the USB driver“ on page 28

Figure 9:Block diagram USB connection



5.5 Functional Units


5.5.1 The Machining Head

The machining head has several tasks. It provides the guidance and mounting for

- the spindle
- the stepping motor for the automatic milling depth adjustment
- the camera for fiducial recognition (option)

Moreover, the working depth limiter is located at the bottom of the machining head. It limits to which depth the drilling or milling tool penetrates the base material.


Figure 10: Machining head front view



- | | |
|---|--|
| 1- Vacuum hose | 6- Milling depth limiter (foot) |
| 2- Camera option: holding block for camera | 7- Knurled screw for adjusting the milling depth |
| 3- Mounting plate for exhaust hose and cable hose | 8- Camera option: camera illumination |
| 4- Camera option: camera illumination | 9- Camera option: aperture and focus setting of the camera |
| 5- Connection head illumination | 10- Spring adjustment pressure force |

5.5.1.1 Machining Spindle with Collet

The machining spindle drives the machining tools, while the collet is responsible for their firm and precise location. The collet is firmly mounted on the machining spindle and from the outside only the tool opening can be seen (1 in following figure).



With this circuit board plotter the collet of the machining spindle is actuated automatically.


5.5.2 Working Depth Limiter



Danger! During work, keep your fingers away from the travel area of the machine!

During the milling of isolation channels in the often slightly bent PCB materials it is of special importance that the milling depth is kept constant. The LPKF *ProtoMat S100* achieves this by means of the mechanical or manual scanning using the working depth limiter. Moreover, the working depth limiter enables the improved removal of the milling dust.

Figure 11: Working depth limiter



1- Foot of the working depth limiter

6.0 Bringing into Service

This chapter describes the switching-on procedure of your circuit board plotter. Some operating steps are explained with the help of the *BoardMaster* software. Therefore it is necessary that you install this software first on the PC with which the circuit board plotter is to be controlled. **Connect the circuit board plotter to the corresponding PC (see „Initial Setup“ on page 17) and install the *BoardMaster* software on the corresponding PC (see following chapter)!**



Caution: Observe the specified temperature range for operation of 15-25°C (59-77°F)!

6.1 Installation

6.1.1 System Prerequisites

The **minimum** system prerequisites for installation of *BoardMaster* are:

- Pentium Processor 1500 MHz or faster
- 256 MB main memory (512 MBytes recommended)
- XGA graphic card (recommended display resolution 1024 x 768 pixels)
- Microsoft Windows 2000/XP
- 16 x CD ROM drive, DVD-drive is recommended for optional DVD for training
- RS 232 interface and USB 2.0 for camera option


BoardMaster requires approx. 40 MB of free hard disk capacity for installation.

6.1.2 Installation

As soon as you have inserted the CD in the PC drive and if the autostart function of this drive is activated, the CD browser will start automatically. Its menu guidance will lead you through the installation of the LPKF programs.

If autostart is not activated on your PC, start the CD browser by double-clicking on the file **SETUP.EXE**.

Figure 12: Component selection



During installation, the appropriate initialization files are assigned to *BoardMaster* by selection of the circuit board plotter. The setup initialization files (*.MCH) contain information on the circuit board plotter used (resolution, max. speed, motion range, etc.), the tool libraries to be used and production phases. These points are treated in detail in the following chapters.




Note for update customers: The initialization file (*.INI) for your existing *BoardMaster* version is copied during installation of the update so that your user-specific settings are not lost.

New and update installation:

During installation of *BoardMaster*, the following window appears:

Figure 13: Component Selection



Select **NEW, FIRST INSTALLATION** if you are installing *BoardMaster* and your circuit board plotter for the first time. The setup program will request you to place the configuration CD supplied with the circuit board plotter and containing the specific INI file in the CD-ROM drive.

If you do not want to use this initialization file (*.INI), e.g. test installation without plotter connected, press <ESC> when Setup requests you to insert the configuration diskette. The Setup program then installs *BoardMaster* with standard settings.

Select **UPDATE INSTALLATION** if the Setup program is to add your present initialization file (*.INI) to your update installation. You will then be requested to select the directory containing the INI file. Here, you can press <ESC> to install *BoardMaster* with standard settings.

6.1.3 Directories Generated During Installation

During installation, the installation program generates a directory "C:\Program files\LPKF50", for storing the programs and other required files as a standard feature.

The following subdirectories are created in the directory "LPKF50" for *BoardMaster*.

- **BMaster** contains the program files for *BoardMaster* as well as all required configuration files.
- **Data** contains the data files for *BoardMaster*. This is the standard directory where all data generated by *CircuitCAM* is stored.
- **cfg_*** Subdirectories for configuration scripts

After installation of *BoardMaster*, the Start menu contains a new program group "LPKF Laser & Electronics", as well as a new linkage on your *Windows* desktop.

6.2 Installation of the USB driver

The USB drivers for the SMCU II of the *ProtoMat S100* will be copied to the PC after *BoardMaster* has been installed.

- › First install *BoardMaster* and then connect the *ProtoMat S100* to the computer via USB.

After the ProtoMat S100 is switched on WINDOWS asks for the drivers for „SMCU II“.

- › Use the WINDOWS USB setup to have the drivers copied from the directory C:\programs\LPKF50\BMasterusb_drv.

6.3 Introduction

This and the following chapters provide basic information on the operating principles and a first impression of *BoardMaster* to familiarize you with the user surface



Note: As a beginner, always read the following chapter carefully **before** starting to work with *BoardMaster* in combination with your circuit board plotter. Chapter 8 then presents a practical introduction into the basic functions of the *ProtoMat S100* and Chapter 9 in the *BoardMaster* functions.

6.3.1 HOME Position and Reference Hole System

The HOME position is a reference point programmed in the software. This point serves *BoardMaster* as a reference position for orientation on the machine base plate. The circuit board plotter can be controlled correctly by *BoardMaster* only when this point is adjusted correctly. The Home position must be located on the reflection axis (reference hole system) of the machine for production of circuit boards coated on both sides. The base material is turned around this reflection axis. Inaccuracies in the HOME position lead to an offset in processing the base material after turning.

By means of the reference hole system the circuit board plotter is able to produce double-sided boards. The reference pins are positioned exactly on the HOME line, thus ensuring the congruency of the top side and the bottom side of the board. Any faults that may occur when the board is being turned are often due to the fact that the reference pins are no longer exactly positioned on the Y-coordinate of the HOME position. The HOME position or HOME point is the reference point for the milling and drilling data that are to be approached. All coordinates are calculated as absolute values with respect to it. Machines with camera-based positioning systems (Vision System) may work without a reference hole system for most of the time.



Note: The parallelism of the reference hole system is ensured only for the current position of the reference hole strips. If you use base material of different sizes later, it will be necessary to drill an additional reference hole in the rear reference hole strip for each format (see Chapter „Creating a New Reference Hole System“ on page 40). The position of the pusher for the various holes should be noted or marked on the circuit board plotter. This ensures parallelism for the various formats and eliminates the possibility of mix-ups.


It is only necessary to reprogram the HOME position in exceptional cases (offset on double-sided circuit boards) or possibly after transport of the machine or loss of the individual .INI file.



Note: In this manual, we assume that the recommended standard settings are made during installation. This applies for the name of the program group as well as the directories created.

Before starting to work with the *ProtoMat S100*, reference holes have to be drilled in the reference hole strips, see chapter "Creating a New Reference Hole System" on page 40.

Figure 14: Reference pin system
S100



- 1- HOME Position
- 2- Reference pin groove
- 3- additional reference hole, rear position

6.4 Switching On the Circuit Board Plotter

Before switching-on, remove all objects from the machine and its travel area. Reference pins must not protrude from the base material. Reference pins serve for fixation and as reference point of the axis of reflection when base material is turned.



Danger! Never reach into the machine during switching-on!

For error-free operation with your circuit board plotter, it is absolutely necessary to observe the switch-on sequence specified below:

- **First switch on the computer**
- **Then switch on the circuit board plotter LPKF ProtoMat at the main switch.**
- **Then start *BoardMaster*. The green operating indicator on the circuit board plotter illuminates and indicates that the machine is ready for operation.**

Otherwise, the communication that takes place when *BoardMaster* is being started cannot be performed.



Note: In very rare cases the error „E 706“ may occur. Click on OK to eliminate this error and wait until the X-axis is again initialized. Then click on the START/STOP button and the machine continues milling without any loss of position.

6.4.1 Starting *BoardMaster*

After installation of *BoardMaster*, the Start menu contains a new program group "LPKF Laser & Electronics", as well as a new linkage on your *Windows* desktop.

Start *BoardMaster* as follows:

- › Click once on the entry **BOARDMASTER 5.0** in the program group **LPKF LASER & ELECTRONICS** in the **START** menu or double click the **BOARDMASTER 5.0** icon on your desktop.



Note: During start-up the following image appears before the main menu or the wizard (input assistance) is displayed:

Figure 15:



This image may be visible for up to 8 seconds, which is related to the communication between the PC and the machine, it does not represent an error. After that, the program start is automatically continued.

After the start of BoardMaster the machine moves to the limit switches +z, -x and -y. Then the machine remains in the tool change position.



Note: If the machine does not move after *BoardMaster* has been started and the machine has been switched on, then check the following:


- Do the light diodes light up as in the representation above? (see figure 7 on page 21)
 - Are all cables correctly connected?
 - If necessary, check the fuses at the mains connection.
- › The machine is then ready for operation.



Other possibilities of operation are described in detail in the chapter „Other BoardMaster Functions“ on page 89 .

After starting LPKF *BoardMaster*, the following prompt appears if the plotter was **not** switched on previously:

Figure 16: Machine Switching On



- › Switch on the circuit board plotter (machine).
- › As soon as the green operating indicator on the circuit board plotter illuminates, click **OK!**



Caution! Clicking **CANCEL** starts *BoardMaster* without contact to the machine, i.e. the port is set to zero. This mode is suitable only for test operation or for editing data. To set the port please refer to Chapter „Serial Interface“ on page 57.


If this prompt remains visible, check whether the machine is connected correctly.



Note: If you previously used a version *BoardMaster* 4.0 or older, the communication to the machine cannot be established immediately due to the changed interface programming. In this case click on **CANCEL** if the prompt **SWITCH ON MACHINE** appears and proceed according to the description in chapter „Serial Interface“ on page 57

After starting *BoardMaster* for the circuit board plotter *S100*, the **TOOL STATUS** dialog box appears:

Figure 17: Tool Status





CAUTION: It is absolutely necessary to establish where a tool is located at switch on. Then, the free tool position can be entered in the tool box. **Note: position 1 = tool 1 all the way to the left, position 10 is all the way to the right in the tool box**

After starting *BoardMaster* for the first time, the **TOOL STATUS** dialog box appears as illustrated above. The actual status, meaning where a tool is located and which position is free in the plotter tool box for this tool, must be defined by the user. Each time the program is restarted, the tool status present the last time the program was closed is displayed. This can then be confirmed simply by pressing **OK**.


If the status displayed does not coincide with the actual status, it is necessary for the user to correct the status.

Then, the program asks whether the tool is to be put back in the tool box upon exiting *BoardMaster*.

6.4.2 Wait Message

As long as *BoardMaster* is waiting for a reply from the circuit board plotter (i.e. circuit board plotter is in motion), a box with a corresponding message is displayed:

Figure 18: Board Master



The box disappears as soon as the head has arrived at the tool change position!



Note: Always wait this long and do not click the Stop button!!

This message is also output when the machine is still busy editing the last command from the command buffer. This is not an error message! It is possible to change to other applications while the box is displayed. As soon as the plotter sends the requested reply to the PC, the box disappears and the program is continued normally.

*After clicking the **Stop** button, an (additional) error message appears:*

Message: “**Do you really want to cancel the current process?**”
Yes No



Note: If you really want to cancel the current process, it is discontinued only after clicking the YES button a number of times. The communication between computer and circuit board plotter is then interrupted.

This message also appears when the circuit board plotter is switched off before *BoardMaster* is switched off, see following chapter.

6.5 Switching Off the Circuit Board Plotter.

When switching off the circuit board plotter, keep to the following order:


1. Close the *BoardMaster* software
2. Switch off the circuit board plotter
3. Switch off the PC

When switching off the circuit board plotter, first quit *BoardMaster* before switching off the machine. In the opposite sequence, recurring error messages are possible, which can be cancelled only by repeatedly actuating the **YES** button.

(Error message: **Do you really want to cancel the current process...**)

Before *BoardMaster* is actually switched off, a menu is displayed asking where the machining head is to be displaced to:

Figure 19: „Go to“ Menu




- › Click on **YES** to make the machine head go to the reference point (i.e. zero position).
- › Click on **YES**, if possible, as after clicking on **NO** the machine must be initialized again at a restart which requires some amount of time.

7.0 BoardMaster User Surface

The following illustration shows the *BoardMaster* user surface:

Figure 20: User surface



- | | |
|------------------------|--|
| 1-Title bar | 5- Working area (only with camera option) |
| 2-Menu bar | 6- Blue cross hairs represent the current position of the mill/drillhead |
| 3-Function bar | 7- Imaging window from head camera (only for camera system) |
| 4-Tool change position | 8- Reference picture „Fiducial“ (only for camera system) |

A job is a completely edited production file containing information on the size of the base material, HP-GL or LMD data used, its positioning as well as all production phases and tool assignments.

The format of such a file is described in greater detail in the following chapters.

You can import the file “tutor.lmd” or any other desired file after starting *BoardMaster* for test and practice purposes by selecting the entry **IMPORT - LMD OR LPR** in the **FILE** menu.

The user surface for *BoardMaster* is subdivided into a number of areas:

- The **Title bar** shows the name of the program indicating the type of circuit board plotter used as well as the name of any job loaded or created.
- The **Menu bar** lists the menus available.
- The **Function bar** contains various buttons, displays and functions for control of the circuit board plotter and for modification of a job.
- The **Working area** graphically displays the current top view of the circuit board plotter.
 - This area is itself divided up into the actual **motion range** of the circuit board plotter (displayed in dark gray) and the area of the **base material** used (displayed in light gray) with the **circuit board data** to be processed. **Only in this area you can lower the head, therefore all data must be placed in this area.**
You can adapt the graphic display of the working area to your specific requirements with the functions in the **VIEW** menu.
- The **Display scroll bars** are located on the right of and below the working area and serve for moving the visible section into the working area.
- The **Current mouse cursor position** is indicated at the left next to the horizontal scroll bar.
- The **Status bar** below the horizontal scroll bar provides information on buttons, displays or areas where the mouse cursor is presently located.
- The **tool changing position** represents the stations 1-10 of the tool magazine.


7.1 Function Bar

The function bar in *BoardMaster* includes functions for positioning and copying projects on the base material as well as for control of the connected circuit board plotter. Moreover, the function bar provides important status information on the machining process.

7.2 Brief Summary of Function Bar

This short summary contains a list of all features in the function bar. The individual features and meanings are explained briefly. Each function includes a reference to the corresponding page in the manual containing a detailed explanation when present. The hot keys for the function are also listed following the page number.


Figure 21: Overview function bar



- | | |
|--|--|
| <ul style="list-style-type: none"> 1- New file (page 69) 2- Display/select active phase (page 50) 3- Import LMD-file (page 69) 4- No function 5- Display/select active tool (page 50) 6- Open job file (page 69); (Strg+O) 7- Save file as job (page 69) 8- Zoom window (page 77) 9- Zoom in x 1,5 (page 77), (Page up key) 10- Tool penetration depth 11- Zoom out x1,5 (page 77), (Page down key) 12- Number of drills or length of milling lines mm 13- Total view of operating area (page 77, („Pos1“) 14- Speed of milling/drilling spindle 15- Previous (page 77) 16- Reload LMD data (also screen refresh) 17- Display: Drilling time in sec. or feed in mm/sec. | <ul style="list-style-type: none"> 18- Phase configuration (page 66) 19- Tool position - dialogbox 20- Vacuum On/Off (not for all machines) 21- Configuration „active Tool library“ (page 57) 22- Controlling functions for Milling/Drilling head (page page 51) 23- Display interface (page 57) 24- Moving Milling/Drilling head in X-/Y-direction 25- Moving Z-Axis -Z / +Z (page 50) 26- Special camera functions (only for camera option, page 54) 27- Display: X-, Y-, and Z-position in mm 28- Vector index display 29- Copy, Shift, Select, Mark (page 50/page 52) 30- „Start“ / „Stop“ (page 53)) 31- Estimated processing time (hr:mm:ss) 32- Open connection to the LPKF internet shop |
|--|--|

7.2.1 Status information

Figure 22: Status-Information-I



1. Interface

This display provides information on the interface set for transferring the control data. Here NULL means that the data is not sent to an interface. When the mouse is moved over this display field, the values set for the interface are indicated in the status bar.

2. Actual position of milling drilling head

This display shows the actual position in all 3 axes.

3. Number of vectors

The number of vectors which have already been processed is displayed (here vector means section of line, "Selection functions" on page 52, causing movement in X, Y, or Z direction).

4. Estimated Processing Time

For current production phase. This display indicates the estimated time in hours:minutes required for processing the enabled production phases. Individual selections are not taken into consideration here.

8.0 Introduction to the Basic Functions



Danger: When using a machine with housing: close housing before setting the machine into operation, and do not open housing while machine is in operation, danger of injury!

With this chapter we want to show step by step the principal procedure for the prototype production of a double-sided unplated PCB by means of *BoardMaster* **specially when using the *ProtoMat S100***. Just follow the instructions and within a short time you will be familiar with the basic work procedure with *BoardMaster* and your circuit board plotter:

- › If this is not already done, switch on the machine at the main switch first!
- › Click once on the entry **BOARDMASTER 5.0** in the program group **LPKF LASER & ELECTRONICS** in the **START** menu or double click the **BOARDMASTER 5.0** icon on your **Desktop** in order to start *BoardMaster*.

The following message appears:

Figure 23: Tool Status

Click on the correct position. If there is not yet any tool within the machine or if the tool magazine is occupied, only click on **OK**.



Note: When the machine is first put into operation there will not be a tool present. Programming and preparation of the tool magazine will be dealt with later in this introduction. In this case, too, just click on OK.

Configuring BoardMaster:

BoardMaster can only communicate correctly with the circuit board plotter when *BoardMaster* addresses the correct interface of the PC and when this interface is correctly adjusted.

- › If this is not already done, define the serial interface by selecting menu **CONFIGURATION** and there the entry **INTERFACE...**, check and if necessary adapt the values correspondingly (see chapter „Serial Interface(s) / USB Connection“ on page 22).

- › If necessary, check the settings of the serial interface in the **WINDOWS- SYSTEM CONTROL** under **System Devices Manager Connections**. Necessary setting parameters are shown in figure 40 on page 58, they depend on the type of circuit board plotter that is connected.



Note: Close the *BoardMaster* program after control and any configuration of the interface adjustment before continuing with this introduction!

- › Click once on the entry **BOARDMASTER 5.0** in the program group **LPKF LASER & ELECTRONICS** in the **START** menu or double click the **BOARDMASTER 5.0** icon on your **Desktop** in order to start *BoardMaster*.
- › Click on the **MOVE TO ... - PAUSE** in the menu bar to move the circuit board plotter to the pause position.

8.1 Creating a New Reference Hole System

The machine is delivered with red reference hole strips inserted in the reference hole groove, however, these strips do not yet contain reference holes. Before producing the first printed circuit board, reference holes have to be drilled into the reference hole strips. Drilling new reference holes also becomes necessary when the reference holes in the red reference hole strips become larger after a time from use and are therefore not as precise as at the beginning. Replace the strip when too many holes are present.



Danger! Remember that the tools are very sharp and may also be hot. Work only with vacuum switched on to prevent injuries from chips!



A new reference hole system can be created as follows:

- › When creating a reference hole system for the first time, remove the base material and drilling panel. If you have already worked with the machine, remove them as well as the reference hole pins.
- › If sufficient space is still present on the old reference hole strip, it can be reused (reference hole strip may be turned around). Otherwise, insert two new reference hole strips into the machine groove, whereby the front reference hole strip should be pressed against the front reference pin in the groove. The distance between the two reference hole strips should correspond approximately to the size of the base material along the X axis. (move the machining head to the pause position to change the reference hole strips; use command Go to...-Pause position on the menu bar).
- › Move the machine head to the ZERO position and remove the foot of the working depth limiter.
- › Select **Spiral Drill Ref. 2.95** in the **Tool** list field (machine changes tool automatically).


- › Move the machine head to the HOME position (**GO TO** Menu, HOME position).
- › Move the machine head from there in the X direction (not Y direction under any circumstances) to a free location on the front reference hole strip with the arrow keys.




Danger: Always work with the vacuum on! Dusts resulting during operation of the machine may pose a health hazard!

- › Switch on motor by clicking  and drill a hole by pressing the raise/lower  button.

Two enquiries follow, asking whether a reference hole is to be drilled and whether the working depth limiter has been removed. Both have to be confirmed with YES.




- › Switch off motor by clicking .
- › Move along the X axis by 295 mm (for basis material 9"x12" or 229 x 305 mm) to the second, rear reference hole strip (on the right-hand side) and drill a hole there as well. (Confirm the enquiries). Do not move in the Y direction under any circumstances.
- › Move machining head to the **PAUSE** position.
- › Insert the reference pin into the fitting tool, such that the chamfered side is protruding. At delivery of the machine, the reference pins are supplied in the accessory bag.
- › Press the pin into the hole now present in the reference hole strip using the fitting tool as an aid. Repeat the process with the second reference pin. Ensure that the pins are tightly seated, because any play in the fitting accuracy has a negative effect on the offset accuracy of the board.
- › Mark old holes with felt-tip pen so that they cannot be mixed up with the new holes.
- › Position pre-drilled base material and drilling panel above reference hole strips. Select the format for the base material so that the reference hole strips do not have to be moved by more than 10 mm, because otherwise the reference hole system loses accuracy.
- › Fasten the base material now positioned with adhesive tape in addition (we recommend Tesakrepp 5250) on all four sides.

8.2 Preparing and putting on base material

Preparing the base material:

- › Now use, for example, an upright drilling machine to drill a 3 mm hole on the middle axis of both short sides at 5 mm distance away from the edge (see following figure):

Figure 24: Drill holes in the base material



- › First put on the drill underlay material.
- › Then place the base material on the machining table.



Note: the tools must be assigned to the tool magazine before milling. The tools must, of course, also be inserted in the tool magazine. This work step is postponed on purpose as BoardMaster can later display which tools are really needed for the corresponding job after the data are read in and prepared. Details on the tools and the tool holder can be found in chapters "The tools" on page 82 and "Tool Holder" on page 55

In order to be able to process data that are prepared using *CircuitCAM* or a similar software, they must first be imported into *BoardMaster*.



For those who are so far unfamiliar with the LPKF milling technology it is helpful to have the base material that is actually processed visibly displayed on the screen. To do this, you can determine this area. The determination has no influence on the course of the production, it is merely an assistance for the view. In case of need, proceed as follows:

Determining the view of the material size:

Determine the size of the base material that is used by reading chapter "Defining the Base Material Size" on page 67 and using the method **Determining the size by moving the machining head** described there. Then continue work from here.

8.3 Working with Production Data and Phases

Importing production data:

The „work instruction“ for *BoardMaster* which determines the way in which the base material is processed is contained in the production data. The data is prepared by *CircuitCAM*, for example. It must be imported first:

You can import LMD production data prepared by software *CircuitCAM* (e.g. TUTOR Fiducial.LMD). In the following we will import a file in LMD format (TutorFiducial.lmd).


- › Import the file TutorFiducial.LMD by clicking in menu **FILE** to the sub-menu **IMPORT** and there on entry **LMD or LPR...** . There you can select a file (e.g. „TutorFiducial.LMD“). This file is located in the directory LPKF50\Data\.

Assigning tools:

In order for *BoardMaster* „to know“ which tool is to be used for each individual production phase (milling, drilling of different sizes, engraving, and so on), a tool must be assigned to each production phase. This is usually done by *BoardMaster*, this is also the case with the import of Tutor.lmd.

Placing production data:

The data are automatically placed in the middle of the machining surface after import of the data. With this function It is possible to place the imported production data anywhere on the base material where they are to be milled later.

- › Place the imported production data or projects by going to menu **PROCESSING** and selecting entry **PLACING...** or click on the button  in the function bar. Then you can move the mouse to the image of the production data and move these by keeping the mouse key pressed.

Saving a job:

- › Having placed all projects, store the job by selecting menu **FILE** and entry **SAVE** to store the job under any name of your choice.



Note: Before starting the machining process, the milling depth has to be manually adjusted. The milling depth can be adjusted by turning the knurled nut on the working depth limiter. When the wheel is turned clockwise, the milling depth is increased, turning counter-clockwise reduces the milling depth.

- Turning the knurled nut by one increment changes the milling depth by approx. 4 µm.
- Turning the knurled nut one complete rotation changes the milling depth by approx. 0.5 mm.



Note: Altogether the following production work steps must be processed in order to produce a double-sided PCB:

- **Marking Drills**
- **Drilling Plated**
- **Milling Bottom**
- **Read Top (only with camera option)**
- **Milling Top**
- **Cutting Outside**



Note for the Read phase (only for option camera or vision system): A Read-Phase must be performed each time when it was necessary to remove the PCB from the machine base plate (e.g. during multilayer production), e.g. „Read-Bottom“ after the PCB was through-plated.

Selecting first production phase:

Each production phase, like „milling the solder side“ (Milling Bottom) must be selected individually and prepared for processing (inserting the correct tool and so on). Now start with the first production phase:

- › First check whether in the function bar in the list field **PRODUCTION STEP (see figure below)** the production phase **Marking Drills** is selected. If this is not the case, select it.

Figure 25: List field „Production Phase“




Configuring tools for automatic tool change:

- › Configure the tool positions by clicking with the right mouse key on

the list field **TOOL** in the function bar (or button ).

A message is displayed asking if the machining head is to be moved to the pause position.


Figure 26:



- › Confirm with **Yes**.


In the current window on the right you see the tools required for this job. These must be inserted in the tool magazine as follows:

Figure 27: Tool positions



- › Now you manually set the „UniversalCutter 0.2 mm (marking)“ on position1 (see figure on following page):
- › Now click on the button at the side to open the „Pos.tool“- window of position 1, and select the tool „UniversalCutter 0.2 mm“.
- › Proceed in the same way for all other tools. At the end the window with the listed tools could look like this:

Figure 28: Listed tools



A mark in front of the tools listed on the left side of the screen indicates that those tools are required for the phases listed on the right side.

Now the tool magazine is equipped and programmed for the job.

- › Click on **OK**.
- › Save the data as job by clicking on **SAVE FILE**.

Marking data:

It is possible to process only parts of this production phase by marking them correspondingly. Therefore the required areas which are to be processed must be selected first. As here the whole production phase is to be processed, all data of this phase are marked.

- › Select **All+** for marking all data.




Danger! Activating the following button in the function bar causes the circuit board plotter to move, danger of crushing! Make sure no persons come within the travel area of the circuit board plotter or come in contact with the tools.

Starting the milling process of the selected production phase:

- › Click on the **Start** button in the function bar to send the marked data of the current production phase via the serial interface to the circuit board plotter.

*Production phase „Marking drills“ is being processed.
The following message appears:*

Figure 29:




- › Click on **OK**.

Select a second production phase:


- › In the function bar in the list field **PRODUCTION PHASE** select the production phase **DrillingPlated** (see figure below).

Figure 30: List field „Production phase“



Mark data:

- › Select **All+** for marking all data.


- › Click on  in the function bar.
The production phase is processed.

Now continue to follow the drill request by inserting the tool (drill) upon request and subsequent clicking on **OK** until the production phase is completely processed.


Select third production phase:

- › In the function bar and in the list field **PRODUCTION PHASE** select the phase **MillingBottom**.


Figure 31: List field „Production phase“



Mark data:


- › Select  for marking all data.

Starting the milling process of the selected production phase:

- › In the function bar click on .

Data of the current production phase is sent to the circuit board plotter via the serial interface. When processing is finished, the following window appears:

Figure 32:




Only for camera option: select next production phase:

- › When the production phase is processed, move the head to **MOVE**

TO/PAUSE. 

- › First turn the base material. To do this, lift it and turn it around its longitudinal axis so that the former bottom side is now on top. Make sure the base material is well positioned on the reference pins.
- › In the function bar and in the list field **PRODUCTION PHASE** select the phase **ReadTop** .

Figure 33: List field „Production phase“



- › Select **All+** to mark all data.

- › Click on **Start/Stop** in the function bar.

The machine automatically traverses to all three fiducials.

After the successful fiducial recognition the main screen is again displayed. You can now see three little crosses on the fiducials.

Select fourth (for camera option fifth) production phase:

- › First turn the base material. To do this, lift it and turn it around its longitudinal axis so that the former bottom side is now on top. Make sure the base material is well positioned on the reference pins.
- › Now select production phase **MillingTop**.
- › Click on **ALL+**.
- › Click on **START**.
- › When the production phase is processed, move the head to **MOVE**

TO/PAUSE. 


When you have performed the previous work steps, you must now process the production phase **Cutting Outside**.

Select fifth (for camera option sixth) production phase:

During this production phase the board is milled out of the base material.

- › In the function bar and in the list field **PRODUCTION PHASE** select the phase **CuttingOutside**.

Mark data:

- › Select  to mark all data.

Start the milling process of the selected production phase:

- › Click on  in the function bar.

The selected data of the current production phase are sent to the circuit board plotter via the serial interface.

- › When the production phase **CUTTING OUTSIDE** is completely processed, move the circuit board plotter to the **PAUSE** position.



Danger! The milled edges of the produced board may be sharp. Danger of cutting! If necessary, wear protective gloves.


The double-sided board is now finished. It may be broken out of the base material with due care. If you want to process the data of other production phases (milling of inner layers of a multilayer and so on) then follow the description above in the same way for these phases. Read the corresponding chapters in the manual.

9.0 BoardMaster Functions

9.1 Changeable Settings

The display fields indicated here can be edited and thereby adapted to your requirements.

Figure 34: Status-Information-II



1. Tool

This list field shows the tool used for the current production phase.

2. Current Production Phase

The current production phase is indicated in this list field.

3. Step Width for Manual Control

This text field allows definition of the step width by which the milling-drilling head is moved each time one of the six arrow buttons (outlined with dotted line in figure above) is clicked.

You can mark the text field and increase or decrease the value in defined steps with the + or - button.

4. Vector Index

This text field allows you to define the vector index. An index is counted with each line segment or arc segment. Here, it is possible to define the vector index at which processing is to be started, for example.

9.2 Positioning Functions



Move Project

You can activate this button to move a project in the operating area. Position the cursor on the project to be moved, press the left mouse key and drag the project to the desired position with the mouse key depressed.

The project appears as a dark area while it is being moved.



Duplicate Project

You can activate this button to duplicate a project and position the copy in the operating area. Position the cursor on the project to be duplicated, press the left mouse key and drag the copy of the project to the desired position with the mouse key depressed.

The copy of the project is represented as a dark area during duplication.



Note: Each time a project is moved or duplicated it is necessary to reactivate the corresponding button.


Click a project with the right mouse key to open the **PLACEMENT** dialog box and display the settings for this project. In this dialog box you can correct the reference point values for positioning projects on the same X and Y coordinates (**align**). If the control key is pressed and held down, while clicking and holding down the left mouse key on the project, the project is moved only in the X or in the Y direction.

You can also use the **PLACEMENT** dialog box for rotating a project (after positioning with the mouse) by changing the setting **ROTATION**.

9.3 Control Functions for Manual Control



Danger! After activating one of the following buttons on the function bar, the connected circuit board plotter is put into motion! Ensure that no one can move into the hazard area of the plotter during the operating phases controlled by *BoardMaster!*



Manual Control

The head can be moved in the directions +X, +Y, -X and -Y with the aid of the arrow keys. Pressing one of the arrow keys once, moves the head by the value entered on the function bar in the entry field **STEP FOR MANUAL CONTROL** in the selected direction. (See "Changeable Settings" on page 50). Motion in the X and Y direction can also be accomplished by holding down the Ctrl key on your keyboard and pressing the arrow keys on the keyboard. The Z-axis can be moved with the keyboard by pressing the Ctrl key and actuating the Page[↑] or Page[↓] key.



Moving by Mouse

After activating this button, the head can be moved to the position in the operating area which you click with the left mouse key. If you continue to hold down the left mouse key, you can move the mouse and the head follows the motion of the mouse after it has reached the mouse starting position. This function allows the head to be moved to any desired location very quickly for defining the material size. To control the XY table with the mouse motion again it is first necessary to activate the button again.



Moving to the Home Position

When this button is clicked, the machining head moves to the Home Position. This position is principally moved to in order to check the existing reference hole system or to produce a new one.



Zero point

When this button is clicked, the machining head moves to the zero point of the X-Y coordinate system. This position is generally moved to before switching the circuit board plotter off.

**Vacuum**

By clicking on this button you can switch the vacuum system on or off. Please note that the vacuum system cannot be switched off when the machining spindle is running.

**Machining spindle on / off**

By clicking on this button you can switch the machining spindle on or off.

**Pause Position**

When this button is clicked, the machining head moves to the Pause Position. This position is used when material is to be exchanged or when material is to be turned round.

9.4 Selection functions

Before selecting, you must have activated all phases to be assigned data and which you want to process. Detailed information on activation is given in the chapter “Phases”. Data must be selected before it can be sent to the plotter for processing. Only data in the activated phases can be selected.

The following buttons are available on the function bar for selecting the data:

**Mark All**

Activate this button to mark all data for the enabled production phases. The data marked are displayed in a lighter color on the monitor.

**Cancel All Marking**

Activate this button to cancel all marking of the data.

**Select Area**

Activate this button to select a data area. For this purpose, press the left mouse key and hold it down while dragging the mouse over the desired area.

This function also selects lines crossing the area. The selected data are displayed in white on the monitor.

**Select Area (only inside)**

Activate this button to mark a data area. For this purpose, press the left mouse key and hold it down while dragging the mouse over the desired area.

This function marks lines crossing the marked area only up to their first support coordinate outside of this area. The marked data is indicated in white on the monitor.



Note: It is necessary to reactivate the corresponding button each time an area is selected.




Add Selected Data to Marking

Activate this button to add selected data to the marking.



Delete Selected Data from Marking

Activate this button to delete selected data from the current marking.



Selected Lines

You can increase or decrease the number in the window with the small arrow buttons to the right. Each number stands for a certain vector (section of line). The entire job is processed vector for vector in the sequence of this numbering. It is possible to select a certain vector or a number of vectors for subsequent marking. For this purpose, it is necessary to select the number of the corresponding line with the aid of the right arrow button. Then, it is necessary to activate the function

“Selected lines” by clicking . You can then increase or decrease the number with the arrow buttons to select each selected vector and display it in white on the monitor. These selected lines can be marked by clicking or added to a marking. If vectors already marked are selected in this manner, they can be unmarked by clicking .

This function can be deactivated by clicking .

Furthermore this function allows to select a project to start with a determined vector index value. Enter the vector value from which the project

is to be processed. Confirm the function with and then the vector value is increased using the keyboard entry (for example by adding a number, e.g. 564 becomes 5640). The subsequent routes are then rep-

resented in white and can be added to the selection by pushing the button.

9.5 Control Functions for Production Phase



Danger! After activating one of the following buttons on the function bar, the connected circuit board plotter is put into motion! Ensure that no one can move into the hazard area of plotter and come into contact with the tools during the operating phases controlled by *BoardMaster*!



Start

Activate this button to transfer the marked data for the enabled production phase to the plotter over the serial interface.



Stop

Activate this button to discontinue data transfer to the plotter after starting.



Caution: After activating the Stop button, the plotter does NOT STOP IMMEDIATELY; first, it continues to process the data in the buffer!

Activation of the Stop button only interrupts transmission of data to the plotter!

9.6 Camera Functions (only for S100 with camera option)

Set Focus

Use the arrow keys to move the machining head with camera until the image is focussed on the base material. Then press this key to have the current Z value stored in the INI file as vocus position.

In order to facilitate the adjustment of the focus, it is recommended to use a piece of paper with text on it. Put this on the working area and then approach the writing. By means of the keys for moving the Z-axis (recommended stepwidth 0.5 mm) the focus can then be adjusted manually.

The following enquiry for setting the position of the camera is to be answered with **YES**.

Focus

Press this button to have the camera moved back to the focus position when it is currently in a different position.

Stop


Pressing this button stops ongoing reading processes of the camera, e.g. when fiducials are being read in.

Measuring function at camera system

When the camera system is being used, a measuring function in the „live“ image of the camera can be used as well.

By clicking on a start point and on an end point (see figure below), distances and sizes can be measured in the displayed camera window.


Figure 35: Measuring function



9.7 Tool Holder

Tool holders that are mounted at the *ProtoMat S100* machine are represented on the screen in the following way:

Figure 36:



The dots below the menu and function bars (see rectangle) represent the tool holders of the machine: The color represents the kind of tool in the holder.

- Green dot:** drill
- Orange dot:** universal milling cutter /micro-milling cutter
- Blue dot:** RF endmill
- Violet dot:** end mills
- Yellow dot:** contour cutter
- Light green dot:** endmill long

Dot displayed in white by the software:

Tool holder is free.

Dot displayed with a red ring around it:

Tool position reserved - tool is presently in the collet

A detailed description of the tools can be found in the chapter „The tools“ on page 82.


10.0 Menu Bar

This chapter introduces the menu functions in *BoardMaster* in their typical sequence of use.

10.1 Go To Menu

This menu contains functions for moving the machining head to the corresponding positions:

Figure 37: Go To Menu




Danger: When an entry in the menu GO TO is selected, the connected circuit board plotter starts moving! The hazard of pinching and crushing exists! For this reason, ensure that no one can enter the motion range of the circuit board plotter during the operating phases!

- HOME** Select this entry to move the machining head to the HOME position (data origin).
- PAUSE** Select this entry to move the machining head to the PAUSE position (standard Xmax/Ymax) .
- Zero Position** Select this entry to move the machining head to the tool changing position (standard Xmin/Ymin).
- Camera >> Head** Select this entry to move the camera (if option is present) to the current machining head position.
- Head >> Camera** Select this entry to move the machining head back to its original position.

10.2 CONFIGURATION Menu

This menu contains all functions required for configuration of *BoardMaster* as well as the connected circuit board plotter:

Figure 38: Configuration menu




10.2.1 Serial Interface

An interface is preset by the manufacturer in the INI-file. If the machine is to be connected to a different interface at your computer (COM2 instead of COM1) or if you used version *BoardMaster* 4.0 or an older version, than *BoardMaster* will first start without communication build-up. The interface and its configuration can then be selected later in *BoardMaster* under „configuration -> interface“. **It is important that the correct configuration is selected which corresponds to the connected *ProtoMat* machine. Otherwise the communication will not be built up correctly.**



Note: When the communication has been successfully established, it is absolutely necessary to terminate *BoardMaster* for a short moment and then restart it so that the modified settings are written in the INI file.

Figure 39: Machine communication



Machine

Adjustable machine configurations.

H100 - 2003-:

ProtoMat H100 built in 2003

H100 -2004-:

ProtoMat H100 built in 2004

H60:

ProtoMat H60

S62 (Firmware 2.4.1):

ProtoMat S62, with USB connection

S62 (Firmware 2.3.3)

ProtoMat S62 (previous firmware version)

S100 (Firmware 2.4.1)

ProtoMat S100

SMCU_2AX:

ProtoMat 91s, 91s/VS, 92s, C20, C30, C30s, C40, C60, C100/HF, M30/s, M60, M100, L60, X60

SMCU_2AX Toolchange:

ProtoMat 95s, 95s/II

SMCU3AX:

ProtoMat D100, M60/3D

Virtual Machine:

Demo-Modus for offline operation

X60:

ProtoMat X60/II

X60 III:

ProtoMat X60 / II

Interface

Usable communication ports of the control computer. Selectable are „RS 232“ or „USB“.

Port

Here the PC connection is selected which is connected to the machine.

Baud rate

57600 (only RS232 connection)

Language

If an error occurs during operation, then *BoardMaster* gives necessary hints to the problem in a dialog. The language of the dialog may be set here.

Write to Comtrace.txt

The dialog between the PC and the machine via the serial interface can be written in a separate file to help error detection. The file produced is called „Comtrace.txt“ and is located in the main directory of *BoardMaster*, C:\Program Files\LPKF50\Bmaster.

The following table lists all parameters of the serial interface which can be set:

Figure 40: Interface parameters

Circuit board plotter	Baudrate	Data bits	Stop bits	Parity	Protocol	Fifo
ProtoMat S100	57600	8	1	none	Hardware	Yes



Note: the FIFO buffer must be switched on (see table above)!

The adjustment of these parameters is done in the *Windows* system control.

Windows 2000/XP: System - Hardware - Device Manager
(Login as „Admin“!!!)

If the circuit board plotter is not correctly triggered after the start of the data transfer, check the connection between PC and plotter.

Also make sure that the parameters of the serial interface in the *Windows* system control match the parameters listed in the table.



Note: The cause of incorrect communication often is an incorrectly adjusted protocol of the serial interface. Make sure that the protocol set is *Hardware-Handshake* and not *XON/XOFF*.

10.2.2 Machine Settings

Select the entry **SETTINGS...** in the menu **CONFIGURATION** to open the following dialog box:

Figure 41: Machine parameter



Note: To prevent a change by mistake of the parameters listed in the dialog field **MACHINE PARAMETERS** if you want to make a deliberate modification you have to click on the button **UNLOCK** to enable the editing of a parameter. The button then changes to **LOCK**, which must be pressed if modifications are to be stored.

UNIT

Click on one of the two options to have the length, diameter coordinates and so on displayed either in inch or metrically.

NAME

This text field displays the type of circuit board plotter as it appears in the *BoardMaster* title bar. This serves only for information purposes and has no effect on the operation.

NUMBER OF TOOL POSITIONS

The number in this text field indicates the number of tool change positions. For the circuit board plotter *ProtoMat S100* this is always 10.

SEND

Click on this button to send the command in the entry field to the left of the button to the circuit board plotter.

For this function it is not necessary to click first on the button **UNLOCK**.

ROTATION

The number in this text field indicates the maximum speed of rotation of the spindle of the circuit board plotter.

SPEED OF MOVING

The number in this text field indicates the maximum speed of movement of the circuit board plotter when the machining head is lifted.

RESOLUTION

The numbers in these two fields define the distance which the circuit board plotter moves in X or Y direction at one step of the stepping motor. Do not change these values under any circumstances as otherwise the correct scaling of the output cannot be guaranteed.

AUTOMOTOR

If there is a check mark the machining motor is switched on before the start of a production phase and it is switched off when the phase is finished.

CONTROLLER

All parameters specific to a plotter are defined in this dialog field. They are stored in an initialisation file (*.INI).

SMCU II-CONTROL

Control type SMCU II for *ProtoMat S100*

BoardMaster is capable to operate two types of control. Selection of the control type is preset for the circuit board plotter selected in the setup.



Note: The type of control should not be changed as otherwise the correct data transfer with the corresponding syntax is no longer possible.

Vacuum table

There must be a check mark in this field if a vacuum table is mounted so that the correct working height is taken into account during milling or drilling. Otherwise there is the danger that e.g. during drilling of reference holes the vacuum table is damaged.

Vacuum table height

The default value of 15 mm is set at the factory. This value should not be changed. The value is activated if the checkmark is set in the field vacuum table.

Camera

If a camera is installed, there must be a check mark in this field.

During installation, the machine parameters of your plotter are read from the initialisation disk that is supplied together with the plotter. Thus all important values like machine size and the position of the *HOME* position (data origin on the axis of reflection) are already programmed at the factory. The circuit board plotter is immediately ready for operation.

All important information like *HOME*-position and area of travel must be sent from *BoardMaster* to the control of the circuit board plotter.

A chain of commands in plotter syntax can be entered in the text field **START LINE**. The commands are stored in the initialisation file when *BoardMaster* is closed and are sent to the circuit board plotter when *BoardMaster* is started.


All entries in the dialog field **MACHINE PARAMETER** are transferred to the plotter when **OK** is clicked to leave the program and they are stored in the initialisation file when *BoardMaster* is closed. Thus they are available at each new start of the program.

10.2.3 Tool Parameter

The *BoardMaster* program provides tool libraries containing tools available from LPKF with all specific tool settings. The tool library files are available in three versions: *.TOL for drilling and milling tools, *.DIS for dispensing needles and *.VAC for evacuation needles (only with LPKF AutoContac). All lists can be changed and stored for later use.

The submenu **TOOL LIBRARY** in the menu **CONFIGURATION** provides access to the various tool libraries:

Figure 42:



Libraries:


Example:

FR4-100.tol-	Processing of FR4 base material
Alu-100.tol -	Processing of aluminium base material

FR4-100.tol is loaded as default. Please select before starting depending on material.

- › Select the entry **MILL/DRILL HEAD** in the menu **CONFIGURATION** in the submenu **TOOL LIBRARY** to open the following dialog box:

Figure 43: Mill/Drill Tool Edit



All tools required for operation of the circuit board plotter are defined in the tool library with their characteristic properties. The individual settings are described here to allow you to change or add additional tools.

NAME

This list field contains the name of the tool. The selection of the name should provide information on the type of tool to facilitate later selection in other program sections. After selecting a tool in the list field, you can display its settings and change them if required. The names selected here must coincide with those in *CircuitCAM*. This name allows automatic tool assignment when importing LMD files.

DIAMETER

The number in this text field indicates the diameter of the tool. This value allows automatic tool assignment when importing LMD files and the display of the actual diameter in the graphic working area.

HEAD DOWNTIME

The number in this text field indicates the time interval in seconds between the command "Lower head" and the command "Raise head" for the drilling tool.

MILL/DRILL

The tool can be defined as a milling or drilling tool by clicking one of these two options.

Z-Hub (in mm)

The standard value for this is 2 mm. When work is to be done without working depth limiter (e.g. drilling vias), then the drilling depth can be adjusted at this position.

DESCRIPTION

An additional description of the tool can be entered in this text field. However, this specification has no significance for the production sequence.

LIFE CYCLE

The number in the text field **MAXIMUM** specifies the maximum cutting path or maximum number of holes for the tool. In the text field **PRESENT**; the cutting path already cut or the current number of holes for the tool is indicated.

The tool change procedure can be started by clicking **REPLACE** and after replacing the old tool, the specification in the text field **PRESENT** is reset to 0.

OPTIMAL SPEED

The speed in the text field **ROTATION** defines the optimum rpm for the machining spindle. The number in the text field **MILLING** defines the optimum feed rate for milling tools.

MILLING INFEEED [MM]

Value in millimeters for milling depth (engraving tools L=36mm) and infeed (cutting mills L=38mm). All milling tools that only machine the surface of the material or engrave it penetrate into the material with this value, after the zero position was detected by the depth sensor prior to that. Cutting mills are not detected by the depth sensor. Then the value only indicates the further infeed.

WORKING MODE...

Here parameter sets or profiles can be assigned to each tool. There are the profiles **THROUGHPUT, BALANCED, QUALITY**. Parameters speed, acceleration and dwell times can be stored for each of the three axes, they apply to „lower head“ (drilling) and „head down“ (milling). These profiles are stored in an MCH-file and are preset for the various working mode profiles.




Note: All changes in the tool library can be stored in a tool file (*.TOL) and loaded again later. The file to be loaded when *BoardMaster* is started can be defined in the machine file “*.MCH” with the command “#INCLUDE”. This also applies for production phases, the dispenser and vacuum tools.

All changes are stored in a tool file (*.TOL) when the **SAVE...** button is pressed and can be loaded again later by pressing the **LOAD...** button.

10.2.4 Heads Dialog Box

The **HEADS** dialog box can be reached by clicking **HEADS** in the menu **CONFIGURATION**.

Figure 44: Heads -Mill Drill



The various tool heads are listed in the left half and the offset associated with the specific heads are listed in the right half:

Mill/Drill head: The milling/drilling head serves as a reference for all other options mounted on the head. Its offset should therefore always be set to $X = 0$ and $Y = 0$.

Camera: The distance between a camera option mounted on the machining head and the machining head is defined here. This can be used for precise positioning for reloading circuit boards already completed.

A detailed description of how this offset is calculated is given in the following chapter.

Auto

When a metal sheet is put on the table, this function is used to calibrate the camera offset automatically. This is no function in the software version for the *ProtoMat S100*.

10.2.5 Adjust Camera Offset

Adjust camera offset (factory setting existent)


- › Select a 0.8 mm drill and drill a hole on a free area of the base material.



Caution: Do not move the machining head anymore!


- › In menu **CONFIGURATION** open the dialog **HEADS**.
- › Click on entry **CAMERA**.

Figure 45: Heads



- › Press button **ORIGIN**.
The button then turns to gray.
- › Quit this dialog by clicking on **OK**.
- › In the menu **GO TO** click on **CAMERA>>HEAD**
- › Now move the head as long as the cross wires of the camera image are exactly in the center of the hole. For better positioning decrease the step width to 0.005 mm.

Figure 46: Camera



- › Open the **HEAD** dialog box again.
- › Press the button **HEAD** to accept this new position.
Then the coordinates in the field OFFSET should change.
- › Quit this dialog with **OK**.


10.2.6 Phase... - Production Phases

All data to be transferred to the circuit board plotter by *BoardMaster* must be assigned to a certain production phase. These production phases define a work sequence which does not require any manipulations by the user. An example of such a manipulation would be through contacting the circuit board or turning the base material. The only exception here is manual tool change. This assignment is prepared in *CircuitCAM* and is accomplished automatically in *BoardMaster*.

Some production phases are already defined in the initialization file. However, you can adapt these production phases to your specific requirements at any time. The names of the production phases must coincide in *CircuitCAM* and *BoardMaster*.

- › Select the entry **PHASES...** in the menu **CONFIGURATION** to open the following dialog box:

Figure 47: Phases



All standard defined production phases are listed in the list field. After selecting a production phase, you can view its settings and change them if required.

Two settings are required for each production phase:

- The color with which the data assigned to this production phase is to be displayed. This setting serves for differentiation of the various production phases on the working area.
- Definition of the circuit board side (visible = component side or reversed = soldering side) for the production phase. Mark the indicator box **REVERSE SIDE** for all production phases for processing the bottom of the circuit board. All other production phases for which the indicator box **REVERSE SIDE** is not marked, are defined for processing the top.

To create a new production phase:

- › Mark the production phase in the list field in front of or in back of the new production phase you want to add.
- › Enter the name of the production phase in the text field.
- › Click **INS ABOVE** or **INS BELOW** to insert the production phase at the corresponding point in the list field.

Press the **SAVE** button to store all changes in the **PHASES...** dialog box in a phase definition file (*.PHS) so that it can be loaded again later by pressing the **LOAD** button.



Note: On one-sided material, the option “**REVERSE SIDE**” should be activated for the phase “**CUTTING OUTSIDE**”! This eliminates the necessity of turning the base material.

Meaning of the phase files

1-2layer.phs

Production of single and double-sided boards

4layer.phs

Production of 4 layer multilayer boards (sequential build-up method)

6layerpin.phs

Production of 6 layer multilayer boards (registration pin method)

soldermask.phs


Cutting of solder foil „system EasySolder“

10.2.7 Defining the Base Material Size

When preparing a new job, it is first necessary to define the size of the base material used. This is necessary to display the actual processing surface available in the working area and therefore allow optimum positioning of the circuit board data.

The material size can be defined in the menu **CONFIGURATION** in the submenu **MATERIAL**:

Figure 48: Material Size



This submenu offers two possibilities for defining the material size:

- Determination of size by moving the circuit board plotter and reading in coordinates.
- Manual entry in the **SIZE** dialog box.

Determining the size by moving the machining head:

Precise determination of the base material size can be accomplished with the circuit board plotter connected with the functions **SET X,Y-MIN** and **SET X,Y-MAX** in the submenu **MATERIAL** in the menu **CONFIGURATION**.

When defining the material size, observe attachment strips and the size of the working depth limitation as well as the position of the reference hole pins.









When a new job is defined; the already defined material size is deleted.



Danger! The following instructions should be read before starting the circuit board plotter as it sets the plotter in motion!

Ensure that no one can enter the motion range of the circuit board plotter. Danger of pinching and crushing!

Also observe the safety precautions for the circuit board plotter!

- › Move the machining head of the circuit board plotter with the arrow keys     to the “front right corner” (X/Y-Min) on the circuit board material.
- › Select the entry **SET X, Y-MIN** in the submenu **MATERIAL** in the menu **CONFIGURATION**.
- › Move the machining head of the circuit board plotter with the arrow keys     to the “rear left corner” (X/Y-Max) on the circuit board material.
- › Select the entry **SET X,Y-MAX** in the submenu **MATERIAL** in the menu **CONFIGURATION**.

After the base material size has been defined, it is displayed in dark gray in the *BoardMaster* working area.

Always observe the specified sequence for setting the coordinates (first front right corner, then rear left corner)!


Manual entry in SIZE dialog box:



Note: This possibility for defining the size should only be used for preparing a job when the circuit board is not connected, because precise entry in consideration of the positioning on the circuit board plotter and the position of the reference holes in the base material is not possible.

Select the entry **SIZE...** in the submenu **MATERIAL** in the menu **CONFIGURATION** to open the following dialog box:

Figure 49: Material size and - position



	X [mm]	Y [mm]
Low corner	0	0
High corner	0	0
Size	0	0

Reversed

Z material values

Free drive level [mm]: 2

Material thickness [mm]: 1.6

Underlay [mm]: 2

OK Cancel

The size of the base material can be defined by manually entering the corresponding values in the text fields. The size calculated from the values in the upper text fields is displayed in the text field **SIZE**.

FREE DRIVE LEVEL indicates by how many mm the tool is moved upward after a machining process.

MATERIAL THICKNESS indicates the thickness of the material to be processed.

UNDERLAY indicates the thickness of the drill underlay. This field cannot be selected if a vacuum table is installed.

After exiting this dialog box by clicking **OK**, the base material area is displayed in dark gray in the working area

Always observe that the minimum values (possibly negative sign) are entered under X-MIN / Y-MIN and the maximum values under X-MAX / Y-MAX.

10.3 File Menu

The functions in this menu serve for handling jobs and projects in *BoardMaster*.

Figure 50: File Menu



NEW Select this entry to create a new job in *BoardMaster*.

OPEN Select this entry to open a job already present in *BoardMaster*. Version 3.x job files can also be loaded. However, it is necessary to reassign the tools, because the tool names are not identical and *BoardMaster* cannot find the old names.
(See "Introduction to the Basic Functions" on page 39)

SAVE Select this entry to store the job opened in *BoardMaster* under the file name indicated on the *BoardMaster* title bar.

SAVE AS... Select this entry to store the job opened in *BoardMaster* under a new file name.

IMPORT

This submenu contains functions for importing production data or projects into *BoardMaster*.

LMD OR LPR...

Select this entry to import LMD files (*CircuitCAM* production data) or LPR files (*BoardMaster* HP-GL projects) into *BoardMaster*. Version 3.x LMD files can also be imported. However, it is necessary to reassign the tools („Assigning Tools“ on page 71 and the production phases, because these names are not identical and *BoardMaster* cannot find the old names.

HP-GL INTO

In this submenu, select the entry
NEW LPR..., to import the HP-GL files into *BoardMaster* and assign them to a new project.

<STANDARD>, To import the HP-GL files into *BoardMaster* and assign them to the *Standard* project.

After importing LMD files, data is positioned immediately in the middle of the working area for the circuit board plotter. Moreover, the production data and the required tools are automatically assigned to the data: If it is not possible for *BoardMaster* to assign one or more tools, the following message appears:

Figure 51: Import




In this case, it is necessary to assign the tools manually in the tool assignment dialog box or to complete the tool library before importing the data again.

After exporting the files, all tools required are listed in the *CircuitCAM* report window.

10.4 Edit Menu

Figure 52: Edit Menu




10.4.1 Assigning Tools

Each job in *BoardMaster* consists of one or more projects. Here, a project is designated to be a circuit board imported as LMD file or HP-GL project.

Select the entry **TOOL ASSIGNMENT** in the **EDIT** menu to open the following dialog box:

Figure 53: Edit tool assignment



Generally, the production data is read in by importing it in the file menu. These projects can, however, also be inserted at this point (LMD file from *CircuitCAM*) or generated (HP-GL files).

The LMD files generated during export in *CircuitCAM* contain the production data for the entire circuit board. The LMD files imported into *BoardMaster* are listed in the project list.

The *CircuitCAM* layers with their production phases (phase) are listed in the field **Phase file/Layer**. Each of these entries contains one or more pieces of tool information (pins) with the assigned tools from the *BoardMaster* tool library (tool).

If automatic tool assignment was not possible (see above), it is necessary to perform it here:

- › Select the **Layer** from the list, for which this assignment is missing.
- › Open the **Pen** list field and check whether a tool is assigned to each "pin".
- › If not, select the tool to be used here from the **Tool** list field.


Repeat this until all tools have been assigned correctly.

To create a new project:

Such a project (LPR) consists of one or more HPGL files.

- › Click **CREATE PROJECT...** to create a new project.
- › Assign a name for the project in the dialog field **ENTER NEW LPR NAME:**

Figure 54: Enter new LPR name



- › Click **OK** to close the dialog box.
- › Enter the resolution for the HP-GL files associated with the project in the text field **UNIT**.

The HP-GL files have a standard resolution of 0.025 mm. If you want to use data with a different resolution, please change the setting for the HP-GL unit:

- › Click **ADD** to add the desired HP-GL files to the project.



Note: All HP-GL files for a project must be located in the same directory.

You can remove HP-GL files from a project by marking the corresponding entry in the list field **PHASE FILE/LAYER** and clicking **REMOVE**.

It is necessary to assign the following information to each HPGL file with production data in **FILE/LAYER**:

- PHASE** In this list field, select the phase to be assigned to the production data.
- PIN/TOOL** Select the pin for the HP-GL file in the **LIST** field pin to which the tool selected in the list field **TOOL** is to be assigned.
- Y=>-Y** Activate this control box to allow simultaneous, coincidental display of both sides of the circuit board for production data generated as a mirror image (generally, the bottom for all production data).

- › Click **SAVE AS** to store the project as an LPR file.

In order to reopen a project stored as LPR file, after restarting the *BoardMaster* program, select the entry **LMD OR LPR...** in the submenu **IMPORT** in the **FILE** menu.

or:


Click **ADD PROJECT** to add a project. This can be an LMD file generated with *CircuitCAM* or an LMD file (HP-GL project file) generated with *BoardMaster*.

10.4.2 Placing Projects

After you have imported or generated the required projects, you can place them in the *BoardMaster* working area. Imported projects are automatically positioned in the center of the working area or the predefined base material.

Select the entry **PLACEMENT...** in the **EDIT** menu to open the following dialog box:

Figure 55: Placement



To place a project:

- › Click **Add...** and select a project from the list. Or:
Select the project whose positioning you want to change on the left side in the list field.
- › Enter the desired scale for the project in the text field **SCALE**.

The default value for the scale is 1, indicating scale 1:1. However, you can also define another scale here, for applications such as front plate and plate engraving.

- › Enter the desired position for the project in the working area in the text field X and Y under **ORIGIN**. These values refer to the *HOME* position for the circuit board plotter and the data origin.

If you do not know the exact position of the data in the coordinate system, you can enter the value 0 and 0 here and position the project in the working area with the aid of the function bar/mouse.

- › Select the appropriate offset for the project in the working area under **ROTATION**.
- › If you want to complete more than one prototype for a project, define the number of multiple boards under **COUNT**. Enter the number of boards in the X direction in the first text field and the number of boards in the Y direction in the second text field.
- › Enter the interval of the boards under **DISPLACEMENT**. Enter the displacement of the boards in the X direction in the first text field and the displacement of the boards in the Y direction in the second text field.

The displacement of the boards in relation to one another must correspond to at least the length and width of the circuit boards, because otherwise, the boards would overlap.

Multiple boards can also be created with the function bar.


Centering a project on the base material:

- › First determine the material size
- › Select the corresponding project in the list field.
- › Click **CENTER** to position the selected project in the center of the base material.

To add other projects for placement:

- › Click **ADD**.
- › Select the project to also be positioned on the base material in the list field:

Figure 56: Select Project



- › Click **OK** to close the dialog box.

To remove a project already positioned:

- › Select the corresponding project in the list field.
- › Click **Delete** to remove the positioned project from the base material.


10.4.3 Select Tools

The **SELECT** dialog window can be used to disable individual tools for processing in the current production phase.

The dialog window shows all of the tools used in the current production phase. Normally all tools in the list are marked (dark background), i.e. enabled for use.

Clicking one of the tools allows it to be disabled (light background) or enabled (dark background). Disabled tools are not used for processing during the production phase, even though they are included in the project.

Figure 57: Select Tools



Example:

A dull drill is detected while drilling. By selecting only this tool, pressing **ALL+** and **START**, only the holes with this tool are repeated, all others are ignored.

Moreover it is possible to define in this list field, whether the **smallest tool is to be used first** (recommended for milling insulation), followed by the next thicker tool, or if the **current tool is to be used first** (for drilling, to avoid unnecessary tool changes).

A detailed description of the tools can be found in the chapter „The tools“ on page 82.

10.5 Reload Dialog Box

The function **RELOAD** serves for reloading a circuit board which has already been completed and cut, in order to drill additional holes, engrave text or separate the conductors for coding.

The prerequisites for using the reload function include a circuit board requiring reprocessing and the circuit board data as LMD file with at least two identifiable points (holes, reference marks, vectors), which can be assigned to the corresponding points on the circuit board.

The main purpose of the reload feature is to position the data so that it coincides with the circuit board to be processed. For this purpose, two identifiable points in the data (reference points) are assigned to the corresponding points on the circuit board to be processed.

When **RELOAD** is selected, the floating dialog box **RELOAD MATERIAL** is opened.

Figure 58: Reload Material



To reload, the following steps are required:



Danger: Activating one of the following buttons on the function bar, sets the connected circuit board plotter in motion! The danger of pinching and crushing exists! Ensure that no one can enter the hazard area of the circuit board plotter during the operating phases controlled by *BoardMaster* or come into contact with the tools!

Work sequence:

- › Fasten the circuit board to be reloaded on the plotter.
- › Import the LMD file with the corresponding data for the circuit board.
- › If not already accomplished, open the **RELOAD MATERIAL** dialog box. Switch on the switch for **Point 1** and select the first reference point on the data (center point of solder eye or hole, corner point).
- › Move the mark to the desired position by clicking the keys



CENTER or CORNER.



- Hole selection only



- Pad selection only

- › Move the machining head with tool installed or the cross hairs on the camera (LPKF CircuitView Option) as exactly as possible to the appropriate point on the circuit board. For this purpose, use the motion keys on the function strip:




- › Then click the **READ** button to store this point.
- › Switch on the switch for **POINT 2** and repeat the procedure for the 2nd reference point.
- › Mark the check box **ENABLE**.
- › Exit the dialog box by clicking **OK** to activate “Reload”.
- › Select the data to be sent to the plotter. The data is converted to correspond to the position of the circuit board after clicking **START**.

Then cancel the mark in the **ENABLE** check box to prevent the data from being aligned for later jobs. Exit with **OK** and close the floating dialog box.

10.6 View Menu

You can adapt the graphic display of the *BoardMaster* working area to your specific requirements with the functions in the **VIEW** menu:

Figure 59: View menu



ZOOM AREA

Select this function to display a freely selectable cutout of the working area to fill the screen. For this purpose, press the left-mouse key and hold down while moving the mouse to define the desired area. You can also select this

function by clicking  on the function bar.

ZOOMING 1.5x

Select this function to increase the graphic display by a factor of 1.5.

ZOOM OUT 1.5x


Select this function to decrease the graphic display by a factor of 1.5.

MACHINE	Select this function to display the entire working surface of the circuit board plotter in the working area.
MATERIAL	Select this function to display the entire base material surface in the working area.
ALL PROJECTS	Select this function to display all positioned projects as large as possible in the working area.
PREVIOUS	Select this function to return to the previous screen display.
BOTH SIDES	Select this function to change back and forth between simultaneous display of both sides of the circuit board and display of only one side of the circuit board.
REAL TOOLS	Select this function switch display of the milled lines in the actual width ON and OFF. The actual width of the milled lines is defined in the tool library.
DEFAULT FONT	Select this function to change back and forth between the Windows system font and the font set under CHANGE FONT for display of the text.
CHANGE FONT...	Select this function to select the font to be displayed when the DEFAULT FONT is deactivated.

10.7 Selecting Production Phase

Before sending milling or drilling data to the circuit board plotter, it is first necessary to select the production phase to be processed. This can be selected on the function bar in the list field **PRODUCTION PHASE**:

Figure 60: Production Phase



Select the production phase to be processed next. Ensure that only one production phase is marked to which an HP-GL file or LMD file has also been assigned. Erroneous selection leads either to erroneous files being processed or no data being transmitted at all.

An example for the sequence for the production phases for a double-sided circuit board is given below:

<u>Process</u>	<u>Production phase</u>
Configuring tools for tool change	MarkingDrills
1. Drilling	DrillingPlated
2. Milling bottom	MillingBottom
Turning base material	
3. Milling top	MillingTop
4. Cutting outside	CuttingOutside

10.8 Automatic Tool Change

The dialog box shown in figure 61 on page 79 can only be called up when machines with automatic tool changing unit are used. If you now open the **TOOL** list field on the function bar, the ten tool positions with their corresponding tool assignment are displayed.

Figure 61: Automatic tool change

Pos.	Tool	Select	Current [mm]	Maximum [mm]	New	Wanted for current job (phase)
1.	Universal Cutter 0.2 mm marking	<input checked="" type="radio"/>	0	50000	<input checked="" type="checkbox"/>	0 Universal Cutter 0.2 mm marking 40 Spiral Drill 1.5 mm Universal Cutter 0.2 mm (8 mil) Spiral Drill 0.6 mm Spiral Drill 0.7 mm Spiral Drill 0.9 mm Contour Router 2.0 mm (79 mil) End Mill 1.0 mm (39 mil)
2.	+Universal Cutter 0.2 mm (8 mil)	<input type="radio"/>	0	30000	<input checked="" type="checkbox"/>	
3.	+Spiral Drill 0.6 mm	<input type="radio"/>	0	3000	<input checked="" type="checkbox"/>	
4.	+Spiral Drill 0.7 mm	<input type="radio"/>	0	4000	<input checked="" type="checkbox"/>	
5.	+Spiral Drill 0.9 mm	<input type="radio"/>	0	4000	<input checked="" type="checkbox"/>	
6.	< unknown >	<input type="radio"/>			<input type="checkbox"/>	
7.	< unknown >	<input type="radio"/>			<input type="checkbox"/>	
8.	< unknown >	<input type="radio"/>			<input type="checkbox"/>	
9.	< unknown >	<input type="radio"/>			<input type="checkbox"/>	
10.	< unknown >	<input type="radio"/>			<input type="checkbox"/>	

Tool Box
 Up
 Down
 Stop at tool exchange



Note: When the program is started for the first time, the tool <UNKNOWN> is assigned to each tool position, i.e. no tool entered. This is intended to cause the user to check the tools in the circuit board plotter magazines and assign the corresponding positions in the TOOL POSITIONS dialog box. It is absolutely necessary to ensure that the tools in the tool box coincide exactly with those assigned in BoardMaster in order to prevent using the wrong tools and therefore malfunctions.

Open the **TOOL POSITIONS** dialog box by clicking the **TOOL** list field with the right-mouse key:

A tool can be assigned to the tool positions 1 to 10 by selecting the tool required for the production phase from the appropriate list field.

If a tool position is not assigned to a required tool, this dialog box is opened automatically when the production phase is started. It is possible to continue only after all tools have been assigned a position!

The tools required for the selected production phase are listed in the list field **WANTED FOR CURRENT JOB (PHASE)**.

The option **SELECT** indicates the tool momentarily located in the machining head.

The **CURRENT** life cycle and the **MAXIMUM** life cycle are indicated following each tool.

It is necessary for the **NEW** check box to be switched on when a used tool is replaced by a new tool in the tool box. The current life cycle is then reset to 0.

When exiting *BoardMaster*, the tool assignments in *BoardMaster* are stored under the name extension *.TLS and automatically reloaded each time *BoardMaster* is started.

11.0 Operating Procedures



This chapter explains all common operating procedures with the circuit board plotter as well as the tools and their application possibilities. **Special applications are also explained, which are not necessarily important immediately for “beginners” and therefore may be confusing at the beginning. As “beginners”, you should, however, always work your way through the following subchapters:**

- Fastening the base material
- Drilling
- Insulation milling
- Contour milling in circuit board material
- Cleaning the circuit board

The remaining subchapters in this chapter can be read later if required when you are familiar with the circuit board plotter.

11.1 Fastening the Base Material


When the machine is started up for the first time, you will note that a double-sided piece of base material is already present on the machine base plate. Moreover, a reference hole system is preset at the factory. If you have to process different sizes of base material, it will be necessary for you to first create a new reference hole system if this is not already existent. This procedure is described in detail in the *BoardMaster* chapter.



The primary preparations are explained in keywords here. **If you are working with a LPKF circuit board plotter for the first time, perform this work only after you have worked through the *BoardMaster* chapter. You will be referred to it at the corresponding point in the manual!**

- › Drill coincidental reference holes in the base material and drilling plate in the X direction (diameter 3 mm). This can also be accomplished with any desired drill press. Note that the diameter is reduced by galvanic throughplating.
- › Move the machining head to the PAUSE position. Insert reference hole pins into the reference hole strips on the left and on the right.
- › Position first the drill underlay material and then the pre-drilled base material on the reference hole pins.

Figure 62: Fixing the board



- 1- Machine bed (aluminum base plate)
- 2- Reference hole pins, 3 mm diameter
- 3- Base material approx. 1.6 mm thick
- 4- Drill underlay material

The reference hole pins hold the circuit board in position. This is particularly necessary during contour milling. On the other hand, they are also used as a reference when turning double-sided circuit boards.



Danger! Switch on the vacuum before milling/drilling! Remember to replace the vacuum filter as required! Inhaling the material dust poses a health hazard!




Note: It is important that no contamination (adhesive tape residues, drilling or milling chips) is present between the individual layers so that the base material lays perfectly flat. Small particles below the base material would have a negative effect on the uniformity of the milling depths.

11.2 The tools

All tools are fitted with spacer rings to ensure the precise pick up and set down of tools. The different tools are marked by different colours:

In addition the diameter is indicated on the spacer rings, e.g. 1 for 1 mm, and .1 for 0.1 mm diameter.

Figure 63: Tools with ring and color code



- 1- Spacer ring with color code

Tool type	Color	Diameter (in mm)
Drills	green	0.2-2.4 ; in 0.1 steps
Universal milling cutter/ Micro--milling cutter	orange	0.1 and 0.25
RF-Endmill cutter	blue	0.1; 0.15; 0.25; 0.4
End mills	violet	0.8; 1.0; 2.0; 3.0
Contour cutter	yellow	1.0; 2.0; 3.0
Endmill long	light green	1.0; 2.0

11.3 Drilling

In addition to milling, drilling is one of the primary purposes of the circuit board plotter. Circuit boards are drilled with special circuit board drills.

It is only possible to drill one circuit board at a time.

Never attempt to drill a number of circuit boards on top of one another! A drilling cover plate is not required. All drills have a length of 38 mm. Further instructions are contained in the Chapter „Practical Tips“ on page 87.




Caution! Before drilling, ensure that the base material is seated tightly! Switch on the vacuum!

11.4 Insulation Milling

Insulation milling is the designation for cutting milled tracks around the later conductors. This insulates the conductors from the remaining copper coating. Various types of tools are available for the different materials and applications (see figure 7 on page 21). Each of these tools produces different milling tracks (see figure 65 on page 84).

Figure 64: LPKF Universal cutter, micro cutter and RF cutter



- 1- Universal milling cutter
- 2- Micro milling cutter
- 3- RF milling cutter

Universal milling cutter

Before milling, it is necessary to ensure that only **sharp** LPKF universal milling cutters (36 mm long) are used. The milling width can be adjusted between 0.2 and 0.5 mm according to the thickness of the tool by changing the milling depth.



Note: It is advisable to degrease the base material with a cleaning spray before processing (degreaser for electronic components). This allows the drilling chips to be vacuumed up more easily.

In principle, the milling width should not be smaller than 0.2 mm. If work is accomplished only with the front-most tip of the milling cutter, the tool wears more quickly than at greater milling depths.

Micro milling cutter

Finer insulation channels can be produced with the LPKF micro milling cutters, however, the service life of these cutters is approx. 10% of that of the LPKF universal milling cutters mentioned above.




Caution! Do not mix up micro milling cutters and universal milling cutters! The two can only be differentiated under a microscope.

RF milling cutter

A special cutter which produces a rectangular insulation channel in one cut has been developed specially for RF technology.

Figure 65: Milling track by LPKF
Universal cutter,
Micro cutter and RF
cutter



Further information is given in the Chapter „Practical Tips“ on page 87.

After processing, it is necessary to clean the circuit boards. This can be accomplished with a brush machine or manually with board cleaners (LPKF accessory). In all cases, it is necessary to rinse the circuit boards thoroughly with water to rinse off any copper dust resulting from brushing.

After rinsing, it is necessary to dry the circuit board well (hot air gun) and then protect it against oxidation with soldering varnish.



Caution! Before milling, ensure that the base material is seated tightly! Switch on the vacuum!

11.5 Contour Milling in Circuit Board Material

The contour milling cutters should always be used for cutting out the circuit board after it is completely machined or for drilling holes with a diameter greater than 2.4 mm when the circuit board is to be cut through in the entire material thickness.

Figure 66: Contour cutter (1) end mill (2)



1- Contour cutter
2-End mill

The motion rate should be reduced for contour milling. The speed varies from material to material. Use only special contour cutters (38 mm long) with a diameter of 1 or 2 mm if possible.

The 1 mm contour cutter should be used for internal cutouts (small inner radius). Due to the lower stability, the feed rate should be reduced to a minimum.

The 2 mm milling cutters are considerably more sturdy, however, remove less material than the 3 mm contour cutters.

So-called "End mill" cutters are used for contour milling on soft RF base materials instead of contour cutters.



Caution! All speeds and feed rates specified in *BoardMaster* refer to FR4 material. Other materials (in the form of libraries) can be selected in the menu CONFIGURATION/TOOL LIBRARY / MILL/ DRILL ... /LOAD. Lower feed rates should be used initially for all other materials.



Danger! Remember that carcinogenic dust (from fiber glass) can occur when machining material such as FR4. Therefore, always work with vacuum switched on. Always use microfilter.



Danger! Vitally hazard gases can occur when machining some materials !

11.6 Milling Wide Insulation Channels

Figure 67: End mill



Wide insulation channels can be cut with a 36 mm long two-tip cutter (End mill). Various diameters are available.

The 3 mm two-top cutter is particularly suited for milling very wide insulation channels (VDE specifications).

11.7 Cleaning Circuit Boards

Before installing the equipment, it is necessary to carefully clean the completely milled circuit boards. This can be accomplished with a circuit board brushing machine or by hand.

To clean by hand, place the circuit board on a level surface. Brush the circuit board in the primary direction of the conductors with a wet circuit board cleaner (e.g. LPKF board cleaner PAD). Brushing is required to remove the oxidation layer and also remove chips in the insulation channel. After brushing, the circuit board should be metallically bright. From now on, the circuit board should only be touched at the edges with gloves. Then rinse off the circuit board preferably under hot flowing water to remove any brushing chips from the insulation channels and then dry with a hot air gun.



Caution! Never blow off with compressed air, because the oil particles contained in the compressed air can cause problems during further processing.

After drying, spray the circuit board with solder varnish on both sides.

12.0 Practical Tips

This chapter contains tips gained from practical experience on various aspects of circuit board production with your circuit board plotter. **We recommend reading these tips before operating the circuit board plotter to familiarize yourself with a few possible sources of error and exclude them.**



Milling depth:

Adjust the milling depth so that engraving is **too deep** rather than too shallow. If the engraving is too shallow, the milling tool wear more quickly.

Evacuation of the milling and drilling chips with the vacuum attachment is also important for precise milling depth.

Milling depth irregular:

Is the machine bed really **clean**? **Adhesive tape residues** or similar can have a high effect on the milling depth.

Milling chips between the machine bed, drilling plate and base material can also reduce the accuracy.

Deformed based material:

Bend highly deformed material so that the sag points downward; then fasten the edges well with adhesive tape.

Loops between milling tracks:

Loops between the milling tracks can occur from incorrect milling sequence, particularly with circles. When a circle is milled counterclockwise with a tool which rotates clockwise, overlapping milling tracks can lead to **fine loops** between the copper surfaces. The cause is a reduction of the cutting speed at the outer edges. The solution here is to define the correct milling sequence in LPKF *CircuitCAM*. The LPKF *CircuitCAM* standard processing already contains the correct milling directions (see LPKF *CircuitCAM* Manual).

Milling burr:

A milling burr can be caused by dull tools or incorrect feed rate. If the structure to be milled allows, this can be corrected by setting deeper. Otherwise, replace tool.

Burr during contour milling:

Burrs during contour milling or **unclean cut edges** result either from a dull tool or incorrect feed rate.

Color of milled channel:

The color of the milled channel provides information on the condition of the tool with some materials. With epoxy materials, dark insulation tracks indicate that the tool is sharp, light tracks that the tool is dull.

Drill burrs:

Drill burrs occur with dull tools: In this case, replace the tool (drill). Another possible cause can be too high speed during lowering of the machining head.

Deviation of drill:	Deviation of the drill occurs particularly with thin tools which are no longer fully sharp. However, it also depends on the surface structure of the material. For example, when the fiber glass structure on FR4 materials is pressed through by the copper, deviation of the drill is unavoidable even with a sharp tool. On materials with additional, removable copper foil (FR4 material with 9 μm or 5 μm Cu coating), deviation of the drill is very low. The holes can be center-punched first in an additional step. This also prevents deviation of the drill.
Glazing of hole:	The hole tends to become glazed by the base material melting when the drill remains in the hole too long after drilling through. These holes then present problems for through-contacting. If necessary, reduce drilling times.
Drills break:	Drills tend to break when the drilling plate has already been used numerous times. The drilling plate should be changed with each new circuit board: If a drill hits against the edge of a hole already present in the base plate, breakage can hardly be avoided. Always remove broken tools from circuit boards and drilling plates.
Uneven milling channels:	Milling channels when milling foil become uneven when air is present below the film. If the film is fastened with stretchable adhesive tape, the film can become wavy after a time. Particularly important here is the evenness of the milling base (LPKF engraving foil base).
Burr with foil milling:	Burrs during foil milling occur either as a result of a dull tool or milling too deeply.
Offsets between top and bottom sides:	Offset between the top and bottom side occurs when the HOME position has not been programmed precisely, the reference hole pins are positioned at an angle or loose.

13.0 Other BoardMaster Functions


13.1 Learning Fiducial (Option)

Here the image processing software for the recognition of fiducials is calibrated. Fiducials are learnt and the scale is adapted. For the S100 circles or drill holes, respectively, can be used as fiducials. Considering the available camera image area, drill holes with a diameter of 1.5mm are especially favourable.

For the calibration proceed as follows:


- › Choose a 1.5 mm drill and drill a hole on the free area on the basis material.
- › Move the camera directly over the hole (see following image). To do this, use function "Camera >> Head" from the menu **MOVE TO**.

Figure 68: Drill hole in camera field



- › Open the dialog **FIDUCIALS** from menu **CONFIGURATION**.

Figure 69: Settings fiducial recognition



- › To start, press the button **CALIBRATE** in the static field.
If the calibration was successful, then BoardMaster displays the following message.

Figure 70: Fiducial recognition




- › Confirm the message by clicking on **OK**.

There may be several reasons if the calibration was not successful, which can be recognized through the corresponding *BoardMaster* message:

Error	Correction
Brightness or image contrast too low!	Adjust setting at the objective and adjust brightness.
Hole not round or too much burr.	Drill again with new tool. Speed for lowering head is too high. Decrease the speed for lowering by adjusting the throttle valve.
After the galvanic process the copper surface is very shining, fiducials are not recognized.	Roughen the surface of the board in the area of the fiducial holes by means of emery paper or similar material.

The representation of the hole to be measured should be as shown in the following figure.

Figure 71:



Here fiducial recognition is finished.

Explanation of the settings:

IMMEDIATELY RECOGNIZED IF HIGHER THAN

The fiducial is considered as immediately recognized if the percentage recognition is higher than the entered value. In this case it is not tried to get an improved result. If the value is smaller, the detected center of the fiducial is moved to the center of the camera image to perform a further recognition.

TRY ON NEXT SPIRAL POSITION IF LOWER THAN

When the recognition is lower than the entered value, the next position in the search area is moved to. The search area is traversed starting from the middle in a square-shaped and helical way. The distance between the search positions is selected such that the whole search area is covered.

MOVE TO CENTER IF IMPROVEMENT IS HIGHER THAN

This parameter is connected to „Immediately recognized if higher than“. If an improvement higher than the entered value is achieved by moving the fiducial to the center of the image, then another displacement is performed. At each recognition the center of the fiducial is determined again, and used when another displacement takes place. This displacement and recognition is continued until the improvement is lower than the entered value, or the value for „Immediately recognized if higher than“ is reached.

SPIRAL SEARCH AREA SIZE

This defines the area in which a fiducial is searched for. This area is checked in a helical way, starting from the center of the fiducial in the LMD data. The area should not be defined larger than 2 mm as the search process may then take a very long time.

SHOW FIDUCIAL FOR

This determines for how many seconds each fiducial is shown in the camera image after a successful recognition before the next fiducial to be searched for is moved to.

MAX. STRETCH THRESHOLD

During fiducial recognition the distances between the recognized fiducials are detected. If the difference of the detected fiducials and the fiducials of the LMD data is too big, then the alignment will not take place. A corresponding error message is displayed. The entered value determines the maximum percentage difference.

REQUIRED NO. OF FIDUCIALS

Here is determined how many fiducials must be recognized so that the alignment can be performed. If the number of recognized fiducials is lower, then an error message is displayed. If the number of required fiducials is set to 3, but 4 fiducials are present in the data and 4 fiducials have also been recognized, then the alignment after 4 fiducials is used.

TRAINED FIDUCIAL

The list field shows the stored fiducials. If an entry is selected from the list, the corresponding image is displayed in the window Trained fiducial. The image loaded when dialog box **FIDUCIAL RECOGNITION** is opened, is again displayed when the dialog box is closed by clicking on **OK** or **ESCAPE**.

LOAD


Click on the button **LOAD** and the image of the fiducial selected in the list and displayed in the window **TRAINED FIDUCIAL** is taken over when the dialog box is closed with **OK** . When the dialog box is closed with **ESCAPE** the image loaded when the dialog box **FIDUCIAL RECOGNITION** is opened will again be displayed.

13.2 Setting fiducials

The fiducials must be placed within the camera range, to ensure that they can be reached by the camera in the "Read_Bottom" or "Read_Top" phase. In the following example, it is assumed that the entire surface area of a 9" x 12" base material board is used. The placing of the fiducials was selected for this material size. When using other base material sizes, the material size and placing must be selected accordingly in *BoardMaster*.


- › Start *BoardMaster*.
- › In the **CONFIGURATION** menu, click on the **MATERIAL** submenu, to define the material size (see chapter „Defining the Base Material Size“ on page 67).
- › In the Tool Library, select **QUICKCHECK**.

Figure 72:



The following window appears:

Figure 73:




The white lines show the boundaries of the camera range (see arrows in the above figure).

- › In the **FILE** menu, click on **IMPORT** and import the file "**Fiducial.LMD**" from the folder **C:/Programs/LPKF50/Data** .
- › Place the LMD file along the white lines (boundaries of the camera range) and duplicate the file by increasing the panel in the x and y directions to 2 (see following figure)




Note: For a 9" x 12" printed circuit board, the values for the distance in X and Y can be seen from the following figure (see arrows).

Figure 74:Placement



The **DISTANCE** is obtained as follows:

Figure 75:




1-Camera range boundary lines 2- Base material 3- Fiducials

› Then click on **CENTER**.

The result should be as in the following figure:

Figure 76: Result Placement



Should the fiducials nevertheless lie outside this area, the values for the distance must be decreased somewhat in the **EDIT / PLACE** menu (see chapter „Placing Projects“ on page 73).

13.3 Adjusting Milling Depth




To adjust the milling depth:

- › To adjust the milling depth, select a milling cutter from the tool list field. The tool change will be done automatically.
- › Move the machining head with the aid of the arrow keys and increment adjustment to a free point on the base material where you can make a cut for checking.
- › Set the motion increment to 10 mm.



Danger: Always work with the vacuum on! Dusts resulting during operation of the machine may pose a health hazard !

- › Switch on the motor by clicking  .

- › Click the  raise/lower button to lower the machining head.
- › Move the machining head with the arrow keys.
- › Click the  raise/lower button again to lift the machining head.
- › Switch off the motor by clicking .
- › Switch off the vacuum system
- › Move the machining head far enough away from the sample cut and check the depth of the cutting line with the aid of the measuring magnifier.

If the desired depth was not reached, adjust the milling cutter higher or lower with the knurled knob and repeat this operation until the desired depth or height is reached.

Manual adjustment of the milling depth

The milling depth can be adjusted by turning the knurled nut on the working depth limiter. When the wheel is turned clockwise, the milling depth is increased, turning counterclockwise reduces the milling depth.

- Turning the knurled nut by one increment changes the milling depth by approx. 4 µm.
- Turning the knurled nut one complete rotation changes the milling depth by approx. 0.5 mm.

13.4 Drilling Reference Holes in Base Material

This is required if you want to use a new piece or difference piece of base material. The values specified here apply for the base material size present when the machine was delivered (9" x 12"). For other base material sizes, it is necessary to set other increments and where applicable, drill new reference holes in the reference strip. To drill reference holes, it is necessary to ensure that the circuit board plotter is ready for operation and *BoardMaster* is opened. Then proceed as follows





- › Move the machining head to the **PAUSE** position by clicking the menu Go to... - Pause position
- › Carefully remove the reference pins with a pair of flat-nosed pliers. Ensure that the red reference hole strips do not slip and are not pulled out.
- › Position the drill template and base material on top of one another centered on the machine board and fasten it on the longitudinal sides with masking tape (we recommend Tesakrepp 5250).
- › Then select **Spiral Drill 3.0 mm** in the tool list field in BoardMaster.
The machine changes the tool.

- › Move to the **HOME** position (menu bar Go to...- Home position)
- › Move the machining head with the aid of the arrow keys and increment adjustment across the base material in the negative X direction (not in Y direction under any circumstances), until an interval of approx. 5 mm is present between the front edge of the base material and drill .
- › Move the machining head 295 mm in the X direction (for this purpose, set increment to 295) and check visually whether a distance of approx. 5 mm is also present between the edge of the base material and drill to ensure that later holes are not drilled outside of the material .



Danger! Switch on the vacuum before milling/drilling! Remember to replace the vacuum filter as required! Inhaling the material dust poses a health hazard!



- › Switch on the motor by clicking .
- › Click the raise/lower button  to lower the drilling head.
- › Click the raise/button again  to lift the drilling head.
- › Switch off the motor by clicking .
- › Switch off the vacuum.
- › Move the machining head back 295 mm in the negative X direction and drill the second hole there after performing the same steps as described above.
- › Check whether the rear hole has been drilled all the way through. If not, move the machining head back 295 mm along the X axis over the rear hole and adjust the working depth limiter lower as required.
- › Redrill the hole according to the same instructions as above.
- › Also check the front hole. If it is also necessary to rebuild it, move the machining head to above this hole and perform the same steps as for the first redrilling operation.


The circuit board plotter only drills the holes in the base material, because they have to be precise within 1/100th mm. On the other hand, the holes in the drilling template can be drilled with a normal drill. If you want to use a different size of base material, first drill new reference holes in the reference hole strip (see also Chapter "Special Features" on page 99).

13.5 Special Features

13.5.1 Tool box dialog box

Access to the tool Box dialog box is possible by clicking **TOOL BOX...** in the menu **CONFIGURATION**.

Figure 77: Tool Magazine



The **TOOL BOX** dialog provides information about the tool magazine of the machine. Moreover, properties can be modified.

Within the tool list, modifications may be made for Name, XY Position, life cycle.

CURRENT

The current working time of the marked tool, in mm.

MAXIMUM

The maximum service life of the marked tool (in mm or strokes)

HEAD UP/DOWN

By means of this button the mill/drill head can be moved upward or downward with the value that is set for the selected tool (function is not required for normal operation)

MAIN/AUX CLAMP OPEN / CLOSE

With this button the collet can be opened or closed if a tool is to be removed or inserted. The clamp should be kept closed to protect the material from wear.

SERVICE

Press the **SERVICE** button: you are asked to enter the service password (see „Service password dialog box“ on page 101). Subsequently all control elements that were so far inactive are then represented as active.

Here, a manual check of the positions preset by LPKF for automatic tool change is possible. Normally, it is not necessary for the user to make any changes, because this has no effect on the milling and drilling. The numerical values entered are a configuration example.

ACCEPT

The coordinates entered can be written over by the momentary position of the machining head by pressing the ACCEPT button. Check the position of the machining head carefully before activating ACCEPT. Clicking **CHECK** moves the head to the corresponding point to check the position.

CHECK

The position of the selected tool is checked. If there is no tool selected, the first position will be checked. The head moves to the set position (when a camera is installed, it moves to the set position).



Danger: Always observe that it is possible to overwrite the current correct positions, thus creating a hazard for the user and possibly causing damage to the machine!

SEARCH (only possible with camera option)

Tool positions 1 to 10 are newly measured. This function is only required for the initial adjustment of the machine at the company site.

INTERPOLATE

The positions are detected using the interpolation method. Basis values are the first and the last position. If you have made modifications, then you must press ACCEPT to store the values.

CHECK TOOL POSITIONS

This function can be used to check the tool change after a calibration has taken place. The positions are checked depending on the checkboxes that are selected. The tool is seized and immediately put back down again. In case a position is not equipped with a tool then the position remains grey and cannot be selected.



Note! The circuit board plotter must be switched on and connected to exit the TOOL BOX WINDOW.

13.5.2 Service password dialog box

For service, the following box appears requesting entry of the password after clicking **SERVICE** in the dialog box **TOOL BOX...** in the **CONFIGURATION** menu.

Figure 78: Service Password



It is then possible to change the settings in the dialog boxes specified.



CAUTION: These changes should be accomplished only by personnel trained in the function and operation of the *ProtoMat S100*! Always observe the operating notes and safety precautions to prevent injuries to humans and damage to the machine! If you are authorized to make such changes, enter the password [bmaster].

14.0 Special Applications

14.1 Front Panel Engraving

It is possible to engrave the front panel (e.g. on electronic housings) with the circuit board plotter. Symbols and labels can be created in this manner.

Figure 79: End mill and universal-cutter



1- Two-tip cutter 2-Universal cutter

When engraving it is necessary to adapt the feed rate to the engraving depth and material.


Use LPKF universal milling cutters or LPKF two-tip cutters.



Danger! When engraving, always work with vacuum! Danger of unhealthy dust!

It is possible to cut through aluminum front panels with a material thickness of up to 3 mm.

14.2 Milling Solder Resist Foils



So-called solder resist foils such as are frequently used in circuit board production, can be completed with the circuit board plotter. The following description assumes complete knowledge of the operation of the circuit board plotter including the *BoardMaster* software. **This chapter can be skipped by beginners for the time being during initial familiarization and read later as required.**

Settings:

Tool:	Micro cutter
Tool diameter:	0.15 mm
Rotary speed:	100,000 rpm
Speed:	10 mm/s

Adjust the milling depths in the unused marginal area of the solder resist foil as follows:

- › Mill a square with dimensions of 2 x 2 mm with the **GO TO** button in *BoardMaster* with motor **and vacuum** switched on to determine the milling depth.
- › Measure the current milling depth (width), correct as required and mill another square to check.
- › Then start the milling operation with the data prepared with the data edited with *CircuitCAM*.
- › After completion of the milling operation, check whether all pads have been cut out. If not, start the milling operation a second time.

15.0 Appendix

15.1 Switching over the device voltage

If it is necessary to change the machine voltage, proceed as follows:



Danger! Before working on the fuses or opening the machine, always disconnect the line power plug to exclude electric shocks!

The LPKF *ProtoMat* electronic box is fused on the primary side as well as secondary side. The line power side fuses (primary side) are located in the line power connection for the control and are accessible from the outside.




Note: To have easier access to the fuses it is recommended to unscrew the right-hand part of the cover using the 20-torx tool (contained in the accessories)!

The voltage value located at the mark (2) is always set (see illustration below)

- › Carefully pull the labeled cover (1 in figure below) out of the line power filter housing with the aid of a screwdriver.
- › Then insert the fuse module into the line power filter housing turned around.


Fig. 80: Voltage setting and fuses



The secondary side fuses are located inside the control. In order to have access to the control board, the machine must be disassembled.

- › Displace table to the rear side of the machine
- › Detach the screws
- › Pull out the upper plate
- › Detach four screws
- › Move the detached lower plate to the rear.


Figure 81: Fixing screws of base plate



1 Screws


Then the control board is accessible, see following figure.

Fig. 82: Control board with fuse holders



- 1- Fuse holder, current for spindle motor
- 2- Fuse holder, current for X/Y/Z axis
- 3- Fuse holder, current for 5V, 24 V

Figure 83: Fuse holder



- 1- Fuse holder
2- Fuse

- › Remove the fuse holder (1).
- › Pull fuse (2) out of holder and exchange it.

The secondary circuits are protected by fine fuses as follows:

Fuse	Type	Circuit
F1	3,15 A T	Spindle motor
F2	2.5 A M	X/Y/Z axis
F3	3.15 A M	+5V , 24V

Reassemble the units in the opposite order as described above for disassembly.

If the table cannot be displacing due to a defective stepper motor, then the machine must be put on its side so that you have access to the control board from the bottom side.

- › Put machine on one side inside the hood
- › Detach 8 screws at the bottom
- › Pull out board with transformer
- › Exchange fuse.

Reassemble the units in the opposite order as described above for disassembly.

Before switching on, always ensure that the head and motor cables are positioned correctly.

The fuses in the primary fuses are located in the line power switch which also contains the line power filter and line power changeover switch (e.g. 230 V/115 V). The fuses should be slow-blow:

- 230 V fuse with 3.15 A / T
- 115 V fuse with 3.15 A / T

15.2 Maintenance

In order to guarantee a long-term and reliable operation of the circuit board plotter, it is necessary to perform some maintenance work within certain time intervals. This maintenance is limited to actions that are simple and easy to execute and hardly need any time. The maintenance intervals given refer to a plotter that is in use on a daily basis.

General checks:

The O-ring seals in the tool holders of the magazine should be greased every 12 months to enable the optimal tool change.

- › Grease with LPKF special grease (item no. 102244) every 3 months.

Caution! Use only small amount of grease!



15.2.1 X Axis, Y-Axis and Z Axis

- Check the guide shafts for the X and Z axis for cleanliness and grease. If the shafts are dirty first clean them (brush or rag) and then regrease lightly with standard commercial machine grease, under all circumstances.
- Caution! Grease the transport spindle for the X axis regularly (LPKF special grease, item no. 102244)!
- › To have access to the Y axis, loosen the two screws at the front and pull out the base plate to the front.
- › To have access to the X axis, pull off the vacuum hose and loosen the two screws of the casing.

Fig. 84: X and Z axis guide shafts





Figure 85: Guide shafts and transport spindle



1- Guide shafts Y-axis

2- Transport spindle Y-axis

15.2.2 Maintenance on Working Depth Limiter

Disassemble and clean the working depth limiter according to the instructions below every three months when the circuit board plotter is used daily.

- › In order to remove the working depth limiter, move the machining head to the zero position.




Danger: Always switch off the circuit board plotter with the main switch before disassembling and cleaning the working depth limiter. Otherwise, a pinching hazard exists from uncontrolled motion of the machining head! There must be no tool in the collet!

After switching off the machine, proceed as follows (the numbers in parenthesis refer to the numbers in the illustration above):


- › Pull the plug from the head illumination (1).
- › Pull the vacuum hose (2) away to the left.
- › Remove the two screws and take off the cooling block (3).
- › Loosen and remove the retaining block (4) using a Torx tool

Figure 86: Removing the retaining block




› Loosen the two external screws on the left (5).

Fig. 87: Sequence for cleaning working depth limiter




- › Pull the spindle slightly to the top and then fix it by slightly tightening the screw (6).

Figure 88:



- › The working depths limiter (7) can then be pressed downward and pulled out to the side for cleaning.

Figure 89:



- › Unscrew knurled nut (8) from working depth limiter, clean thread with the brush supplied and lubricate **with graphite grease**.
- › After cleaning reinstall the working depth limiter in the opposite order. **Ensure that the retaining block fits in the groove in the working depth limiter and that the knurled knot is engaged in the retaining plate! The knurled knot must be able to rotate.**

- › Then assemble the retaining block.
- › Connect vacuum hose and head illumination again

If the plastic foot of the working depth limiter needs to be exchanged, e.g. because it scratches the material or if reference holes are to be drilled, then press the foot slightly and pull it out downward.

- › To mount the foot, press it upward and let it engage, take care to hold the machining head and keep it fixed with the other hand.



Danger: Danger of injury during the mounting of the working depth limiter if there should still be a tool in the collet!


For daily use of the circuit board plotter the foot needs to be exchanged approx. every four weeks.

15.2.3 Maintenance instruction for Machining Head

Depending on the use of the machine the collet of the SF-Spindle should be cleaned from time to time at a *ProtoMat S100* system.

- › Remove the connector of the head illumination (1).
- › For cleaning, remove any tool that might still be in the collet.
- › Dismount the foot of the working depth limiter (2).


Figure 90: Machining head



15.2.3.1 Cleaning the collet

For the cleaning of the collet we recommend to use a special pipe brush (2) of the appropriate size.

Figure 91: Cleaning the collet



Caution! Do not clean with compressed air! This would damage the collet.

15.3 Checking and adjusting the tool positions by means of the camera

It may be necessary to check and adjust the tool positions in the magazine if there are problems occurring during tool change.

- › In order to check and adjust the tool positions of the magazine by means of the camera, first remove the tools from the magazine.
- › Put measuring insert (1 in the following figure, cap of the vision system, item no. 115 789) into the tool holder position that is to be checked.

Figure 92: Measuring insert



- › Close the hood
- › In the menu bar choose **CONFIG** and then **TOOL BOX** to open the tool dialog box. (A first setting is already stored stemming from the first installation of BoardMaster at the factory site).
- › In the tool list click on the tool position that is to be checked
- › Press the **SERVICE** button
You are asked to enter the password
- › Enter password BMASTER
- › Press button **CHECK** (the number indicates the position to be checked)
- › Move the processing head above the tool position using the arrow keys of the main dialog in the background until the cross hairs are centered over the tool position.
- › Click on button **ACCEPT**
Then the tool position is entered. Repeat the process with other tool positions if these are to be checked, too.
- › Quit the tool dialog with **OK**
- › Open the hood and remove the measuring cap from the tool magazine.
- › Open the tool magazine dialog under **CONFIG** in the menu bar
- › Confirm the enquiry „Move to pause position“
- › Insert the tools again in the tool magazine according to the tool list.
- › The measured settings are stored in the INI file. Quit and restart BoardMaster so that the values are taken over.



Note: If there occurs a disturbance during the measurement and no value can be measured for a position or the image in the camera field is blurred, it may be necessary to adjust the focus of the camera (see „Camera Functions (only for S100 with camera option)“ on page 54).

15.4 Checking and adjusting tool positions without camera

The tool magazine must be completely filled with tools in order to check and adjust the tool positions in the magazine without a camera. There must be no tool in the collet and the hood must be closed.

- › In the menu bar press **CONFIG** and then **HEADS**

*There must be no offset entered in this field, should there be entered an offset then replace it by entering value zero. Close the dialog with **OK**.*

- › Open the „**Configuration ... tool magazin**“ dialog in the menu bar.

- › Press the **SERVICE** button

The password is enquired

- › Enter password BMASTER

- › Use the mouse key to displace the dialog box to the bottom of the screen, as you need to have access to the menu bar.

- › Click on **OPEN COLLET/AUX. CLAMP**

- › Use the mouse key to click on the first position in the tool list

- › Press **CHECK**

The machine moves to the first position of the tool magazine.

- › Enter a high step width, e.g. 35 mm, in the main dialog under Z

A message is displayed asking if the movement border is to be reached. This message always appears when the value entered under step width reaches the area of the limit switches.

- › Confirm with **YES**

- › Press button **MOVE IN - Z DIRECTION**

The machine head moves downward

If the correct value is adjusted, the machine head moves completely to the bottom and upward again without the tool getting stuck in the collet or being removed from the magazine.

If the value is not correctly adjusted and the machine head does not move downward completely or the tool gets stuck, then modify the values for X or Y in the main dialog using small step widths of 0.1 mm and test by renewed moving of the head until the head can move downward completely and without problems.

- › Store the correct value by pressing the button **ACCEPT**.

- › Do the same for each tool holder position.

- › At the end quit the tool dialog box with **OK**


- › *Quit BoardMaster* and start it again so that the values stored in the INI-file are taken over.

15.5 The Teach-In Dialog Box

BoardMaster offers the possibility of programming drilling and milling data from a template (film or circuit board) with the aid of a Teach-In process. For this purpose, fasten the template to the circuit board plotter and move to the individual positions to be programmed with the aid of the camera image in LPKF CircuitView (option). The HP- GL file completed in this manner can be read into *BoardMaster* after programming and output to the circuit board plotter.

When **TEACH-IN** in the **EDIT** menu is called, the following dialog box appears.

Figure 93: Teach-In



STEP [MM]

The values entered under **X** and **Y** [mm] indicates the distance moved when the motion buttons (+X, -X, +Y and -Y) are pressed once. To program the holes in an IC enter a value of 2.54 mm here. This corresponds to a pad interval of 1/10".

HEAD:

The command for lifting or lowering the head can be programmed by clicking one of the two radio buttons (**UP**, **DOWN**). The head remains in the selected position until the other radio button is activated. This function is not used to create a drilling file, but only for programming milling or contour data.

RECORD MOVEMENTS:

All movement command are stored in the selected file when this check box is activated.

PEN:

The pin number entered in this editing field is written to the selected file as the **Select pin** command. This allows all drilling data even with different diameters to be combined in one drilling file. Example: Pin 1 for 0.7mm, pin 2 for 0.9 mm, etc.

+X, -X, +Y, -Y:

These buttons serve for moving to a desired position. If one of these buttons is clicked, the machining head moves in the selected direction by the value entered under **STEP**.

EXIT:

Clicking this button discontinues the Teach-In process and closes the recorded drilling or milling file.

CREATE FILE:

After clicking this button *BoardMaster* requests entry of the name of a file in which the data to be programmed are to be stored. Here, it is possible to either create a new file or to write over a file already present.

APPEND FILE:

Pressing this button, selects a drilling or milling file which already exists to which the additional drilling or milling data are to be appended. The new data are appended at the end of the selected file.

PIN [SP]:

The pin or tool number selected under Pin is added to the drilling or milling file as the Select Pin (SP) command when this button is clicked. It serves for differentiation of the individual drill diameters.

PLOT [PA]:

With the aid of this button, the head (when **RECORD MOVEMENT** is switched off), can be moved at angles not equal to 90°.

DRILL [PD;PU;]:

Press this button to program a hole at a position moved to previously. This causes the command sequence **Pen Down, Pen Up** to be written into the file. This command chain corresponds to a drilling command for the circuit board plotter.

Procedure

- › Fasten the template (film or circuit board) on the circuit board plotter as parallel as possible to the axis
- › Open the **TEACH-IN** dialog box in the Edit menu
- › Press the key **CREATE FILE** to create a file in which the data is to be stored. Enter a name for the file.

After you have entered the corresponding name, the **TEACH-IN** dialog box reappears.

- › Switch on the option **RECORD MOVEMENTS**, before starting the reading operation.

The file to be created is an HPGL file meaning that it is also written according to the scheme for an HPGL file.

- › First enter the desired pin number under **PIN** and then click the **PIN (SP)** button.
- › Then move with the aid of the motion keys (+X, -X, +Y, -Y) to the hole positions to be read in and press the **DRILL (PD;PU)** button.
- › After reading in all of the required holes, the data is stored automatically, you can exit the **TEACH-IN** dialog box by pressing the **EXIT** button.

The coordinates recorded are then available in the HPGL file created previously.

- › Now select **IMPORT - HPGL TO - NEW LPR...** in the file menu, select the HP-GL file just created and enter a name for the new LPR project
- › To produce something with this newly created file using *BoardMaster* and the machine, open the **EDIT PROJECT** dialog box to assign all required product phases and tools to the HP-GL file. Moreover, set the unit corresponding to the machine resolution (e.g. 0.0079375) in the **EDIT PROJECT** dialog box (this value is also given in the settings **SETTINGS DIALOG BOX** in the **CONFIGURATION** menu).

Please do not forget to reset the unit back to the original value after completion of this operation.

- › Then continue as with LMD files imported from CircuitCAM.

16.0 Options

16.1 Installing the camera

The camera system for automatic fiducial recognition enables the detection of the position of a panel or PCB on the table. The camera is installed as follows.

uEye System requirements:

PC with Pentium III CPU or equivalent
Free USB 2.0 Port
Windows 2000/XP or
Linux Operating System

Getting started:

①



Install Software first.

Setup will start automatically
or run setup.exe on the CD


②



Attach camera

Driver will install
automatically

③




Start uEye Info or Demo

uEye Demo will show
the first pictures

In order to mount the camera (1 in following figure) at the machining head, proceed as follows:


- › Remove the aluminium block (2) at the machining head.

Figure 94: Mounting the camera




- › Fix the camera flush-left at the machining head using the screws that are supplied (see following figure).

Figure 95: Fixing the camera



- › Connect the camera cable on top of the camera (3) and then connect the cable to the PC. To run the cable, use the free position of cable brackets (4) at the exhaust hose.

Figure 96: Camera cable guidance



- › Plug the cable for the illumination of the camera into the top slot (5) on the left side of the camera .



Caution! After the installation of the camera the camera check box in the parameter dialog must be activated (see figure 10.2.2 on page 59) and the spring force at the mill/drill head must be adjusted (see „Spring setting at the machining head“ on page 123). Moreover, the camera focus must be determined (see figure 9.6 on page 54) as well as the camera offset (see figure 10.2.5 on page 64).


16.2 Mounting the Vacuum Table

The vacuum table enables the fixing of rigid, flexible and flex-rigid material free from distortion and warping. Thus fixing with adhesive tape is no longer required. The table is connected to the exhaust system and consists of the table and the sintered board.

To mount the table, it should be moved to the PAUSE Position.


- › Connect the vacuum hoses of the exhaust system to both sides of the vacuum table (bayonet lock)
- › Screw the vacuum table to the base plate

Figure 97: Fixing screws vacuum table



1- Screws for fixing the vacuum table

Figure 98: Vacuum table, connection to vacuum hose




1 Connection hoses of exhaust system

2 Sintered board


- › Press the sintered board into the vacuum table.
- › Unscrew the rear of the hood
- › Remove the screws from the exhaust adapter inside of the rear
- › Remove the exhaust adapter
- › Remove the seals for the vacuum table from the connections for the exhaust adapter

Figure 99: Connections to exhaust system, backside



- 1- Rear wall
- 2- Exhaust adapter
- 3- Connections vacuum hoses (equipped with seals if no vacuum table is connected)

Figure 100: Backside open



- 1 Connection vacuum hoses
- 2 screws to be removed from the inside

- › Screw the connecting pieces to the backside
- › Insert O-ring seals
- › Put on exhaust adapter
- › Screw on the screws on the inside of the machine
- › Screw tight the rear part of the hood



Caution! After the vacuum table is mounted, the machine settings must be adjusted and a check mark must be set in the field vacuum table in the parameter dialog so that the correct working height is taken into account (s. "Machine Settings" on page 59)!

For a fast disassembling the removal of the rear part is not required:

- › unscrew the table
- › loosen the hoses (bayonet lock)
- › provide hoses with seals




Caution! Take care that during disassembly the vacuum hose remains beside the machine and does not get in the way of the table, otherwise the table will be blocked!

16.3 Spring setting at the machining head

Depending on the option that is used with the circuit board plotter, the spring at the machining head needs to be adjusted. There are four different settings, see following figure.

- 1 = Standard or basic setting, no options present
- 2 = Machine with camera option
- 3 = Machine with vacuum table
- 4 = Machine with camera and vacuum table

Figure 101: Spring adjustment, machining head view from the right side



1–4 Spring settings
5- Spring head

6- Spring adjustment screw

- › To adjust the spring, loosen the screw (**6** in figure above) and let the spring engage in the position according to the option that is used. Then tighten screw again.

17.0 Technical Data

Machine operating voltage: 100-140 VAC / 200-260 VAC
 Power consumption: 300 VA
 Speed of machining spindle: 15.000 - 100.000 rpm.
 Permissible humidity: max. 60%
 Operating temperature: 15-25°C (59-77°F)
 Weight (without/with hood): 42 kg / 55 kg
 Dimensions (WxHxD): 650 x 520 x 750 mm
 Airborne noise at workplace: 71dB (A) without vacuum
 Minimum conductor width: 0.1 mm
 Minimum conductor interval: 0.1 mm
 Minimum hole diameter: 0.15 mm
 Motion range: 12" x 9"
 Repetition accuracy: +/- 2.5 µm
 Positioning accuracy: +/- 5 µm
 (after warming-up phase)
 Machining spindle: 3-Phase-Motor 15,000-100,000/min.
 Tool change: Automatic (10 stations)
 Tool mount: 1/8" clamping collet
 Drilling capacity: max. 150 strokes/min.
 Resolution (minimum motion step): 0.00025 mm (0.25µm)
 Motion rate: 150 mm /sec. (max.)
 Milling depth adjustment: pneumatic sensing
 X/Y drive: Incremental motors, precision spindle
 Z stroke: approx. 38 mm
 Applications: All 1 and 2-sided types of circuit board with usual equipment density (FR3, FR4, FR5, G10), flexible substrates, RF-substrates, milling cut-outs in front-panels, drilling test adapters, structuring film layouts, solder frames for PCB assembly, as well as SMD fine conductor technology, contour milling, front panel/plate engraving, multilayer up to 8 layers in combination with LPKF MiniContac and MultiPress

18.0 Declaration of Conformity (German)

EG Konformitätserklärung

im Sinne der EG Maschinenrichtlinie 98/37 EG, Anhang II A.

Der Hersteller / Inverkehrbringer

LPKF Laser & Electronics AG
Osteriede 7
D-30827 Garbsen

erklärt hiermit, dass folgendes Produkt

Produktbezeichnung: Fräsbohrplotter

Serien-/Typenbezeichnung **ProtoMat S100**

den Bestimmungen der (den)oben gekennzeichneten Richtlinien -
einschließlich deren zum Zeitpunkt der Erklärung geltenden Änderungen
- entspricht.

Bei einer nicht mit dem Hersteller abgestimmten Änderung der
bezeichneten Maschine verliert die Erklärung für dieses Gerät ihre
Gültigkeit.

Wir unterhalten ein von der BVQI zertifiziertes Qualitätssicherungs-
system nach ISO 9001 und haben daher bei der Entwicklung und
Herstellung nachstehende EG Richtlinien und EN Normen beachtet.

Folgende harmonisierte Normen wurden angewandt:

- EN 292-1:1991 Sicherheit von Maschinen - Grundbegriffe, allgemeine Gestaltungsleitsätze - Teil 1: Grundsätzliche Terminologie, Methodik
- EN 292-2:1991+A1:1995 Sicherheit von Maschinen - Grundbegriffe, allgemeine Gestaltungsleitsätze - Teil 2: Technische Leitsätze und Spezifikationen
- EN 349:1993 Sicherheit von Maschinen - Mindestabstände zur Vermeidung des Quetschens von Körperteilen
- EN 1050:1996 Sicherheit von Maschinen - Leitsätze zur Risikobeurteilung
- EN 626-1:1994 Sicherheit von Maschinen - Reduzierung des Gesundheitsrisikos durch Gefahrstoffe, die von Maschinen ausgehen - Teil 1: Grundsätze und Festlegungen für Maschinenhersteller
- EN 50110-1:1996 Betrieb von elektrischen Anlagen
- EN 60204-1:1997 Sicherheit von Maschinen - Elektrische Ausrüstung von Maschinen - Teil 1: Allgemeine Anforderungen
- EN 61000-6-1:2001 Elektromagnetische Verträglichkeit (EMV) - Teil 6-1: Fachgrundnormen - Störfestigkeit - Wohnbereich, Geschäfts- und Gewerbebereiche sowie Kleinbetriebe
- EN 61000-6-2:2001 Elektromagnetische Verträglichkeit (EMV) - Teil 6-2: Fachgrundnormen - Störfestigkeit - Industriebereich

- EN 61000-6-3:2001 Elektromagnetische Verträglichkeit (EMV) - Teil 6-3: Fachgrundnormen - Fachgrundnorm Störaussendung - Wohnbereich, Geschäfts- und Gewerbebereiche sowie Kleinbetriebe
- EN 61000-6-4:2001 Elektromagnetische Verträglichkeit (EMV) - Teil 6-4: Fachgrundnormen - Fachgrundnorm Störaussendung - Industriebereich
- EN 55022:1994 A2 Grenzwerte und Messverfahren für Funkstörungen von Einrichtungen der Informationstechnik, Änderung A2:1997

Folgende weitere EU-Richtlinien wurden angewandt:

- EMV-Richtlinie 89/336/EWG
- Niederspannungsrichtlinie 73/23/EWG

Ort: Garbsen
Datum: 08.06.2005

(Unterschrift)
Herr Stephan Wenke

Die Erklärung bescheinigt die Übereinstimmung mit den genannten Richtlinien, beinhaltet jedoch keine Zusicherung von Eigenschaften. Die Sicherheitshinweise der mitgelieferten Produktdokumentation sind zu beachten.

19.0 Declaration of Conformity

EC Declaration of Conformity

according to EU Machine Guidelines 98/37 EC.

Manufacturer

LPKF Laser & Electronics AG
Osteriede 7
30827 Garbsen
Germany

herewith declares that the following product

Product name circuit board plotter

Series / Type designation **ProtoMat S100**

is a machine according to EU Machine Guideline 98/37 EC.
Any modification to the designated machine not coordinated with
manufacturer invalidates this declaration for this machine.

We maintain a quality assurance system certified by BVQI according to
ISO 9001 and have therefore observe the following EC Guidelines and
EN Standards in development and production of the machine:

Harmonized Standards:

- EN 292-1:1991 Safety of machinery - Basic terms, general principles for design - Part 1: Basic terminology, methods
- EN 292-2:1991+A1: 1995 Safety of machinery - Basic terms, general principles for design - Part 2: Technical principles and specifications
- EN 349:1993 Safety of machinery - Minimum gaps to avoid crushing of body parts
- EN 1050:1996 Safety of machinery - Principles for risk assessment
- EN 626-1:1994 Safety of machinery - Reduction of risks to health from hazardous substances emitted by machinery - Part 1: Principles and specifications for machinery manufacturers
- EN 50110-1:1996 Operation of electrical installations
- EN 60204-1:1997 Safety of machinery - Electrical equipment of machinery - Part 1: General requirements
- EN 61000-6-1:2001 Electromagnetic compatibility (EMC) - Part 6-1: Generic standards - Immunity for residential, commercial and light-industrial environments
- EN 61000-6-2:2001 Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments
- EN 61000-6-3:2001 Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments

- EN 61000-6-4:2001 Electromagnetic compatibility (EMC) - Part 6-4: Generic standards - Emission standard for industrial environments Note 2.1
- EN 55022:1994 A2 Information technology equipment - Radio disturbance characteristics - Limits and methods of measurement Amendment A2:1997

The following additional EU Directives were applied:

- EMC 89/336 EEC
- Low voltage operating equipment 73/23 EEC

Ort: Garbsen
Datum: 08.06.2005

(Unterschrift)
Herr Stephan Wenke

This Declaration confirms conformance with the specified guidelines, however, is not a guarantee of properties. The safety precautions in the product documentation supplied are to be observed..

20.0 Index

A	
Airborne noise	124
B	
Base material	5, 36, 81
Baudrate	22
BMaster	28
BoardMaster	5, 11
Boundaries of the camera range	94
Bringing into service	26
C	
Camera	56, 64, 89, 118
Camera functions	54
Camera offset	64
Caution	5, 17
Centering a project	74
Centering project	74
CircuitCAM	5
Cleaning	86
Configuration	68
Control functions	53
Conventions	4
Copper laminate	5
Create project	72
D	
Danger	5
Data	28
Deleting a project	75
Dimensions	124
Display scroll bars	36
distance	95
Drilling	83
E	
Engraving	102
F	
Feed rate	63
FIFO	22
Font	78
Front view	21
Function bar	36
H	
Hardware-Handshake	59
Head downtime	62
HOME position	29, 56
housing	39
HP-GL	70
I	
III	5
Intended Use	5

J	
Job	35
K	
Konformitätserklärung	125
L	
Layer	72
Life cycle	63
Light dot	64
LMD	70
Load	67
Loops	87
LPR	70
M	
Machine greenhorn	5
Menu bar	36
Milling	83, 84, 102
Milling depth	87
Motion range	36
N	
Note	5
O	
Operating temperature	124
Optimal speed	63
Origin	73
P	
Parameter	50
PAUSE position	56
Permissible humidity	124
Phase file	72
Phases	66
Placement	73
Power consumption	124
Processor	26
Production phase	78
Q	
QuickCheck	93
R	
Rotation	63, 74
S	
Safety Notes	14
Scale	73
Serial interface	57
Service	101
Set	68
Setting fiducials	93
Solder resist foil	5
Solder resist foils	102
Sources of error	87
Spacer ring	82

Start line	61
Start of BoardMaster	31
Status bar	36
Symbols	5
T	
Target Group	5
Teach-in	115
Terminology	5
Title bar	36
Tool changing position	36, 56
Tool Parameter	61
Tutor.job	35
U	
USB	26
USB cable	16, 23
USB connection	18, 23
USB driver	28
USB repeater	16, 23
V	
Vacuum	82, 98
Vacuum system	16
Vacuum Table	120
Vector index	50
W	
Weight	124
Windows	26
Working Depth Limiter	108
workplace	14
X	
X Offset	64
Y	
Y=>-Y	72
Z	
Zoom area	77

